

Planer

Model 10055

Owner's Manual

For Models Manufactured Since 03/2025



Oliver Machinery
1-800-559-5065
921 Thomas Ave SW
Renton, WA 98057

info@olivermachinery.net
WWW.OLIVERMACHINERY.NET

Stock Number: 10055.201
Manual Version: 1.0.2



READ AND UNDERSTAND ALL INSTRUCTIONS IN THIS MANUAL BEFORE ATTEMPTING TO ASSEMBLE OR OPERATE THE MACHINE.

FOLLOW THE INSTRUCTIONS AND THINK SAFETY!

THE OWNER OF THIS MACHINE IS SOLELY RESPONSIBLE FOR THE SAFETY OF ANYONE USING THIS MACHINE. SUCH RESPONSIBILITY INCLUDES BUT NOT LIMITED TO THE FOLLOWING:

- **PROPER ASSEMBLY, OPERATION, INSPECTION, MAINTENANCE, AND RELOCATION OF THE MACHINE.**
- **PROPER TRAINING FOR THE OPERATORS AND ENSURES THIS MANUAL IS AVAILABLE AT ALL TIMES.**
- **USAGE AUTHORIZATION.**
- **USAGE OF SAFETY AND PROTECTION DEVICES. UPDATED MANUAL MAY BE ONLINE.**

OLIVER MACHINERY DISCLAIMS ANY LIABILITY FOR MACHINES THAT HAVE BEEN ALTERED OR ABUSED. OLIVER MACHINERY RESERVES THE RIGHT TO EFFECT AT ANY TIME, WITHOUT PRIOR NOTICE, THOSE ALTERATIONS TO PARTS, FITTINGS, AND ACCESSORY EQUIPMENT WHICH THEY MAY DEEM NECESSARY FOR ANY REASON WHATSOEVER.

**** SAVE THIS MANUAL FOR FUTURE REFERENCE. ****

PROP 65 NOTICE

WARNING: Drilling, sawing, sanding, or machining wood products can expose you to wood dust and/or other chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

Some examples of these chemicals are:

- Lead from lead-based paints.
- Crystalline silica from bricks, cement, and other masonry products.
- Arsenic and chromium from chemically treated lumber.

Avoid inhaling wood dust and other harmful chemicals. Use a dust mask and other safety devices for personal protection.

For more information, go to <http://www.P65Warnings.ca.gov/wood>

Table of Contents

| | | | |
|--|-----------|---|-----------|
| Introduction | 5 | Accessories..... | 25 |
| Specifications | 6 | Cutter Inserts..... | 25 |
| Identification | 9 | Mobile Tool Stand | 25 |
| Safety..... | 10 | Operation..... | 26 |
| General Safety Guidelines | 10 | Step 1: Preparation..... | 26 |
| Safety Guidelines Specific to Planer | 11 | Step 2: Setting the Depth of Cut..... | 27 |
| Electricals..... | 13 | Step 3: Determining the Feed Direction | 28 |
| Minimum Circuit Size Requirement | 13 | Step 4: Planing Wood to Desired Thickness | 28 |
| Grounding | 13 | Common Wood Planing Problems..... | 30 |
| Indoor Use Only | 13 | Snipe | 30 |
| Electrical Wiring | 13 | Chipping..... | 30 |
| Setup | 15 | Indentation | 30 |
| Shop Preparation | 15 | Grooves or ridges along the plane direction .. | 30 |
| Space Requirement | 15 | Fuzzy Grain | 30 |
| Electricals..... | 15 | Maintenance | 31 |
| Lighting | 15 | Maintenance Schedule | 31 |
| Safety Labels..... | 15 | Rotate/Replace Cutter Inserts..... | 32 |
| Dust Collection | 15 | Inspect / Replace Poly V-Belt..... | 33 |
| Receiving | 16 | Inspect / Adjust Extension Tables..... | 34 |
| Unboxing | 16 | Adjust Cutterhead Height Scale..... | 34 |
| Inventory | 17 | Depth Stop Positive Stop Adjustment | 35 |
| Assembly | 18 | Anti-Kickback Fingers Inspection..... | 36 |
| Headstock Handwheel Installation..... | 18 | Troubleshooting | 37 |
| Dust Shroud Installation | 18 | Mechanical / Electrical Issues..... | 37 |
| Extension Table Installation | 19 | Finish Quality Issues | 39 |
| Waxing | 19 | Wiring Diagram | 40 |
| Dust Collection | 19 | Parts List | 41 |
| Bench Mounting (Optional)..... | 19 | Top Cover | 41 |
| Controls and Components | 20 | Motor and Cutterhead | 42 |
| ON / OFF Switches..... | 20 | Head Casting..... | 43 |
| Overload Protection Reset Button | 20 | Base | 44 |
| Depth of Cut Adjustment | 20 | Maintenance Record | 51 |
| Feed Rate Selector | 20 | Notes | 52 |
| Material Removal Gauge..... | 21 | Warranty and Service | 53 |
| Depth of Cut Limiter..... | 21 | Appendix..... | 54 |
| Depth Stops..... | 21 | US Standard – Metric Conversion Chart..... | 54 |
| Digital Readout (DRO) | 22 | | |
| DRO Calibration..... | 22 | | |
| Components for Planing Wood | 23 | | |
| Test Run | 24 | | |

Introduction

Thank you for choosing Oliver! This manual contains important information on safely setting up, operating, and maintaining this machine. Please take the time to read through this manual and make sure you understand all instructions.

While this manual may provide tips on optimizing the result of your workpiece, the manual is not intended as a substitute for formal woodworking training. If you need to know how to safely complete a woodworking task, please consult knowledgeable and qualified sources before proceeding further.

We made every effort to keep this manual up-to-date. Instructions, specifications, drawings, and photographs in this manual should match the machine delivered. If you find anything that seems confusing in this manual, or if some instructions are not available, please check our website for an updated manual:

WWW.OLIVERMACHINERY.NET/MANUALS

Alternatively, you can contact our technical support for help:

1-800-559-5065

Before calling, please note the manufacture date and the serial number. You can find the information on a nameplate on the top cover. The information allows the support staff to properly troubleshoot the issue and determine if an updated manual is available for your machine.

Please let us know how well this manual serves you. If you have any suggestions, please call the number above or email us at:

info@olivermachinery.net

We love to hear from our customers and make improvements.

| OLIVER | | 15" THICKNESS PLANER | |
|---------------------------------------|---------------------------------------|---|--|
| | | Model Number: 10055 | |
| Motor: 2.5 HP, 230V, 1Ph, 60Hz | Full-Load Current Rating: 10.5A | Date: | |
| Cutterhead: Helical, 40 Inserts | Cutterhead Speed: 5600RPM | S/N: | |
| Feed Rates: 12 and 22 FPM | Max. Depth of Cut: 1/8" | WARNING Avertissement FOR YOUR OWN SAFETY, PLEASE READ INSTRUCTION MANUAL BEFORE OPERATING PLANER. ALWAYS USE PROPER EYE AND RESPIRATORY PROTECTION. WHEN SERVICING, USE ONLY IDENTICAL REPLACEMENT PARTS. DO NOT EXPOSE TO RAIN OR USE IN DAMP LOCATIONS. A. TOUTE PREVENTIVE, LIRE LE GUIDE D'UTILISATION. NE PAS EXPOSER A LA PLUIE ET NE PAS UTILISER DANS LES EMPLACEMENTS HUMIDES. Mfd. for Oliver in Taiwan | |
| Min. Stock Thickness: 3/16" | Min. Stock Length: 8" | | |
| Max Cutting Width: 15" | Max Cutting Height: 6" | | |
| Net Weight: 135lbs | | | |
| | | | |

Specifications

Quick View

| | |
|------------------------|---|
| Model | 10055 Planer |
| Stock Number | 10055.201 |
| Motor | Induction motor 2.5HP, 230V, 1Ph |
| Max. Stock Width | 15" |
| Max Depth of Cut | 3/64" (full width) 1/8" (stock less than 6-1/2" wide) |
| Dimensions | 48-3/4"(L) x 28"(W) x 18-1/2"(H) |
| Footprint | 23-1/4"(L) x 19"(W) |
| Fully Assembled Weight | 146 lbs. |
| Warranty | 1 Year (Motor and electronics) 2 Years (All other parts) |

Product Dimensions

| | |
|--|----------------------------------|
| Width x Depth x Height (Fully Assembled) | 48-3/4"(L) x 28"(W) x 18-1/2"(H) |
| Footprint | 23-1/4" (L) x 19"(W) |
| Fully Assembled Weight | 146 lbs. |

Shipment Info

| | |
|------------------------|---|
| Package Type | Wood pallet with corrugated paper board cover |
| Content | Planer and accessories |
| Dimensions | Approx. 29-1/2" (L) x 27-1/4"(W) x 21"(H) |
| Weight | 171 lbs. |
| Approximate Setup Time | 30 minutes |
| Must Ship Upright | Yes |
| Stackable | No |

Electricals

| | |
|--------------------------|------------------------|
| Power Requirement | 230V, 1Ph, 60Hz |
| Full Load Current Rating | 10.5A |
| Recommended circuit size | 15A |
| Power Switch Type | Safety lock-out switch |
| Connection Type | NEMA 6-15 plug |
| Overload Protection | Equipped |

Motor

| | |
|--------------------------|---------------------------------|
| Motor Type | Induction motor |
| Horsepower | 2.5HP |
| Speed | 3450 RPM |
| Efficiency | 80% |
| Power Transfer Mechanism | Poly V-belt and pulleys |
| Bearing type | Permanently sealed ball bearing |

Planer Capacity and Performance

| | |
|--------------------------------|--|
| Maximum Stock Width | 15" |
| Maximum Depth of Cut | 1/8" (Stock less than 6-1/2" wide) 3/64" (Full width) |
| Maximum Stock Thickness | 6" |
| Minimum Stock Thickness | 3/16" |
| Minimum Stock Length | 8" |
| Feed Rate | 12 or 22 FPM |
| Number of Cuts Per Square Inch | 104@12FPM 62@20FPM |

Cutterhead and Carriage

| | |
|---|--|
| Cutterhead Type | Oliver HCX helical shearing cutterhead |
| Cutterhead Diameter | 2-3/8" |
| Cutterhead Speed | 5600 RPM |
| Number of Cutter Inserts | 40 |
| Number of Rows of Cutter Inserts | 4 |
| Cutter Insert Type | Four-sided, indexable carbide |
| Cutter Insert Diameters | 15mm x 15mm x 2.5mm |
| Cutting Angle | 79.3° |
| Skew Angle | 12° |
| Cutter Insert Screw Tensioning Torque | 55 lbs.-inch |
| Infeed Roller Type | Rubber |
| Outfeed Roller Type | Rubber |
| Headstock Height Change Per Turn of Crank | 1/16" |

Measurements

| | |
|--------------------------------|---|
| Measurement Units | Inch/mm |
| Primary Measurement Device | Digital readout |
| Digital Readout Resolution | 0.005"/0.05mm |
| Digital Readout Accuracy | +/- 0.0025"/0.05mm |
| Additional Measurement Devices | Manual thickness scale Material removal gauge Depth stops |

Table

| | |
|------------------|---|
| Table Dimensions | 48-3/4" x 15" (With extension tables) 23-3/4" x 15" (Without extension tables) |
| Material | Steel |



Safety

| | |
|----------------------------|----------|
| Number of Dust Ports | 1 |
| Dust Port Size | 4" |
| Anti-Kickback Device | Equipped |
| Minimum CFM Required | 600 CFM |
| Sound Rating @ 2' distance | 90 dB |

Others




| | |
|------------------------|-----------------------------|
| Serial Number Location | On the top cover |
| Spare Parts Included | 5 Oliver HCX cutter inserts |
| Certification | CSA 175370 |
| Country of Origin | Taiwan |

Identification



Safety

Oliver Machinery has made every attempt to provide a safe, reliable, easy-to-use piece of machinery. Safety, however, is ultimately depending on the individual machine operator. **Before operating this machine, please become familiar with the following safety labels and guidelines.**

| | |
|--|--|
|  DANGER | This indicates an imminently hazardous situation which, if not avoided, WILL cause death or serious injury. |
|  WARNING | This means if the warning is not taken seriously, it CAN cause death or serious injury. |
|  CAUTION | This means if the precaution is not taken, it MAY cause minor or moderate injury. |
| IMPORTANT | This is a tip for properly operating the machine to avoid machine damage. |

General Safety Guidelines

1. **FAMILIARIZE** yourself with all safety instructions found in this manual. Know the limitations and hazards associated with this machine. Do not operate or service this machine until you are properly trained.
2. **ELECTRICAL GROUNDING**, when done properly, reduces the risk of electrocution, shocks, and fire. Make certain that the machine frame is electrically grounded and that a ground lead is included in the incoming electrical service. In cases where a cord and a plug are used, make certain that the grounding plug connects to a suitable ground. Follow the grounding procedure indicated in your area's electrical code.
3. **DISCONNECT** the machine from power before performing any service, maintenance, or adjustments. A machine under repair should be RED TAGGED to show it should not be used until the repair is complete.
4. **EYE PROTECTION**: Always wear an approved safety face shield, goggles, or glasses that comply with ANSI Z87.1 and CSA Z94.3 standards. Common eyeglasses are not safety glasses and may not provide adequate protection.
5. **EAR PROTECTION**: Use hearing protective devices where the noise exceeds the level of exposure allowed in Section 1910.95 of the OSHA Regulations. When in doubt, use it.
6. **OTHER PERSONAL PROTECTION**: Before operating this machine, remove tie, rings, watch, and other jewelry. Roll up sleeves above elbows. Remove all loose outer clothing and confine long hair. Wear professional work boots to protect your feet from injuries and slippage. Do not wear gloves unless it is instructed to perform a particular step(s) in the manual.
7. **GUARDS**: Keep machine guards in place for all applicable operations. If any guards are removed for maintenance, DO NOT OPERATE the machine until all guards are reinstalled.

8. **WORKPLACE SAFETY:** Keep the floor around the machine clean. Scrap material, sawdust, oil, and other liquids increase the risk of tripping or slipping. Be sure to clean up the table before starting the machine. Make certain the work area is well-lit and that a proper exhaust system is used to minimize dust. Use anti-skid floor strips on the floor area where the operator normally stands and mark off the machine work area. Provide adequate workspace around the machine.
9. **ACCESS CONTROL** should be enforced so only trained personnel can access the work area and operate the machine. Use a padlock to lock the power switch when the planer is not in use.
10. **STAY ALERT** at all times. Do not operate this machine while under the influence of drugs/alcohol or when not feeling well.
11. **NEVER STAND ON MACHINE.**
12. **REPLACEMENT PARTS:** Use only genuine Oliver Machinery replacement parts and accessories recommended for this machine. Generic parts made by other manufacturers may create a safety hazard and WILL void the factory warranty and other guarantees.
13. **PROPER USE:** Do not use this machine for anything other than its intended use. If used for other purposes, Oliver Machinery disclaims any real or implied warranty and holds itself harmless for any injury or damage which may result from that use.

Safety Guidelines Specific to Planer

Before Work Begins:

1. **USE ONLY NATURAL, SOLID WOOD.** Do not plane any material such as plywood, MDF, OSB, laminate, or anything that can disintegrate during operation. Do not plane treated lumber or anything that contains harmful chemicals, as this will spread wood dust that contains such harmful chemicals. Do not attempt to plane any workpiece that contains loose knots or foreign materials.
2. **CHECK CUTTER INSERTS:** Make sure cutter inserts are sharp, clean, and free from damage. Forcing dull/damaged cutter inserts to work invites accidents and impacts finish quality. Use the recommended amount of torque to securely fasten all inserts onto the cutterhead.
3. **SERVICING CUTTER INSERTS:** Wear heavy-duty leather gloves to protect your hands when installing new cutter inserts or rotating the existing ones. Ensure the cutterhead is thoroughly clean before installing the insert. Debris between the cutter insert and its seat can create uneven pressure, causing the insert to break, and body injuries may occur.
4. **SUPPORT LONG WORKPIECE** with auxiliary stock feeding rollers/tables. This helps to avoid injuries and improve the quality of the finish. Bolt down the machine to prevent tipping.

When Using the Planer:

1. **DUST COLLECTION SYSTEM** is required for this planer. Please make sure the system is turned on and provides enough suction before starting the planer.
2. **KICKBACK** happens when a workpiece is ejected, usually towards the infeed side of the planer, during operation. **This can cause serious injuries or even death.** The operator should be cautious about possible kickbacks.
 - **ALWAYS** wear proper protection devices.
 - **NEVER** stand directly behind a workpiece while it is being fed into the planer.
 - **NEVER** look inside the planer when the motor is running.
 - **NEVER** plane boards that are shorter than 8", as mentioned in the specifications.
3. **PROPER WORKPIECE FEEDING** avoids kickback. Never start the machine with the workpiece engaging the cutterhead. Never start feeding until the planer has reached its full speed. Ensure feed rollers apply an adequate amount of pressure on the workpiece.
 - **KEEP HANDS AWAY FROM THE CUTTERHEAD** when the planer is running.
 - **NEVER** force a workpiece through the planer. Reduce the depth of cut as needed.
 - **ONLY** plane one board at a time.
 - For warped workpieces, face joint the workpiece with a jointer before planing.
4. **STUCK WORKPIECE** can only be removed after the planer is powered off and the cutterhead comes to a complete stop. Raise the headstock to dislodge the stuck workpiece from the anti-kickback fingers for removal. Do not use hands or push sticks to force-feed a workpiece through the planer, as it can result in severe injuries and/or machine damage.
5. **DEPTH OF CUT SETTINGS:** Do not force the planer to exceed the maximum depth of cut capacity found in the specification. Failing to comply can cause machine damage and injuries. Reduce the depth of cut for hard materials as that increases the planer's workload.

After Operation

1. **STOP THE MACHINE** if the operator leaves the machine for any reason.
2. **WAIT** until the machine comes to a complete stop.
3. **CLEAN UP** the work area before departure.

Electricals



WARNING

Faulty electrical work can cause electrocution and is a fire hazard.

All electrical work must be completed by a licensed electrician and must meet the local electrical code in your area, or the warranty is void.

Minimum Circuit Size Requirement

| Stock Number | Minimum Circuit Size Required |
|--------------|-------------------------------|
| 10055.201 | 15A |

Please ensure the electrical circuit for this machine meets the minimum circuit size requirement. The minimum circuit size requirement applies to a dedicated circuit that provides power to one 10055 Planer. If more items are sharing the same circuit, consult a qualified electrician to ensure the designated circuit is properly sized for safe operation.

If a circuit is available but does not meet the minimum circuit size requirement listed above, a new circuit must be installed for this machine.

Grounding



WARNING

Improper grounding can cause electric shock, fire, and equipment damage.

Proper grounding reduces the risk to the operator in the event of electrical malfunction or breakdown. This machine must be connected to the grounding conductor when available, and all grounding connections must meet or exceed the electrical code requirements in your area. Furthermore, all grounds must be verified and must meet or exceed the electrical requirement of the machine.

Indoor Use Only

This machine is designed for indoor use only. Operating this machine outdoors increases its exposure to moisture, which in turn increases the risk of electric shock.

Electrical Wiring

This machine is pre-wired for 240V with a cord and plug. Using an extension cord to bring power to the planer is not recommended. If you must use an extension cord to connect to a power source, select a durable cord type with a high-temperature rating (90C° or above). Use the minimum amount of extension cord as needed.

Minimum cord size (AWG) required based on amperage draw and length of the cord:

| <i>Amps</i> | Power Cord Length | | | | |
|-------------|--------------------------|---------|---------|----------|--------------------|
| | 25 feet | 50 feet | 75 feet | 100 feet | > 100 feet |
| < 5 | 16 | 14 | 14 | 14 | Not Recommended |
| 5 to 8 | 14 | 14 | 14 | 12 | |
| 8 to 12 | 14 | 14 | 12 | 10 | |
| 12 to 15 | 12 | 12 | 10 | 10 | |
| 15 to 20 | 10 | 10 | 10 | NR | |
| 21 to 30 | 10 | NR | NR | NR | |



WARNING


Use properly sized wires that meet or exceed the power requirement of your machine. Using undersized wires may cause overheating and increase the risk of fire and machine damage.

Setup

Shop Preparation

Space Requirement

The dimensions of this machine are 48-3/4" (L) x 28" (W). You will need additional space to manipulate your workpiece and connect to the dust collection systems.



Electricals

If you plan to install this machine in a permanent location, make sure a properly sized circuit and electrical outlet are available nearby. Please refer to "Electricals" on page 13 for details regarding electrical requirements.

Lighting

Adequate lighting is needed to operate this machine. Overhead, non-glare lighting should be installed.

Safety Labels

If this machine introduces a new safety hazard to your workplace, display proper warning signs in highly visible locations.

Dust Collection

Wood dust created by this planer is a health hazard. Position this planer in a spot where it has access to a dust collection system.

Dust masks should be available for using the planer.



CAUTION

Use a dust collection system that is rated above 600 CFM. Doing so improves air quality in the workplace and prevents the machine from jamming.

When the machine is further away from the duct collector, the effective suction and CFM measured at the dust ports decrease. Ensure there is significant suction at the dust port so dust and debris can be effectively removed from the machine.

Receiving

If this planer is delivered to you, please check for any significant damages on the packaging before signing the delivery confirmation.

This machine has a shipping weight of 171 lbs. and a net weight of 146 lbs. Please be sure help is available to move the machine to its final location.



IMPORTANT

If items are damaged, please call us immediately at **1-800-559-5065**



WARNING

10055 Planer has a gross weight of 171 lbs. and a net weight of 146 lbs.

Safe moving techniques and proper lifting equipment are required, or serious personal injury may occur.



WARNING

Do not lift your shipment by the strap. The straps are not designed to hold the total weight of your shipment. They may snap without warning and cause serious injury and machine damage.

Straps may spring back violently when released and cause injury. Always wear safety goggles and gloves when removing the straps.








Unboxing

1. The corrugated paperboard cover is secured by the straps on the wood pallet. Remove the straps to remove the top cover and the packaging inside.
2. Inside the package, you should find the planer and two boxes that contain all loose parts and accessories.
3. Remove the mounting bolts at the corners of the planer to release the planer from the pallet.



Inventory

Carefully unwrap the packaging and make sure all components are included in the shipment. Lay out all items received and inventory them.

| <i>Item</i> | <i>Description</i> | | <i>Qty.</i> |
|--------------------|--|---|--------------------|
| 1 | Dust shroud with 4" dust port |  | 1 |
| 2 | Dust shroud mounting thumb screws |  | 4 |
| 3 | Headstock handwheel |  | 1 |
| 4 | Headstock handwheel knob assembly (Knob, flat washer, and spring) |  | 1 each |
| 5 | Spare cutter inserts and mounting screws |  | 5 each |
| 6 | Extension tables |  | 2 |
| 7 | Extension tables socket head cap crews |  | 8 |

NOTICE: If you cannot find an item in the list above, please check if it is still attached to the packaging. Occasionally, the item may have been pre-installed in the factory. See "**Parts List**" on page 41 to check if a component is included or installed.

NOTICE: This machine comes with various standard-sized, non-proprietary parts that can be purchased at local hardware store. If any of these parts are missing, getting them from the local store is the fastest way to get the machine running. We can also deliver any missing parts.

Additional Items Recommended for Machine Assembly and Maintenance

| Item | Purpose |
|---------------------------|---|
| Safety glasses | Protection. |
| Leather gloves | Protection. |
| T-25 Trox driver bit | Cutter inserts rotation/replacement (55 lbs.-inch). |
| Torque wrench/screwdriver | Cutter inserts rotation/replacement (55 lbs.-inch). |
| Metric Hex Wrench Set | Parts installation & removal. |
| Philips Screwdriver | General maintenance. |

Assembly

This planer is mostly assembled in the factory. There are a few more items to set up before the machine is ready for a test run. The approximate time for cleaning and assembly is approximately 30 minutes.

Headstock Handwheel Installation

1. Slide the washer and spring (inventory item #4) into the headstock handwheel knob.




2. Install the handwheel on the right side of the planer. Rotate the handwheel so the flat surfaces on the handwheel and the shaft are aligned and the handwheel is fully inserted.
3. Thread the knob into the handwheel shaft and tighten.



4. The spring-loaded knob keeps the handwheel from rolling when it's fully tightened. Untighten the knob by 1-2 turns to allow the handwheel to move.


Dust Shroud Installation

1. Locate the four screw holes on the headstock for mounting the dust shroud.



2. Use the provided thumb screws to secure the dust shroud.

TIP: The bi-directional dust shroud design allows wood chips to exit from the left or right side of the planer. Left is the preferred direction as it allows optimal dust extraction.



Extension Table Installation

1. Locate the screw holes near the end of the planer's main table.
2. Align the holes on the extension tables and install the mounting screws.
3. Ensure the mounting screws are fully seated and tightened to support the extension tables.



Waxing

The steel planer table and extension tables have a low-resistance finish. To minimize stock feeding resistance, wax these surfaces with paste wax before first use and wax routinely thereafter.

Dust Collection

This wood planer can generate a lot of wood shavings and dust. You must connect this planer to a dust collection system so all dust and wood chips can be effectively removed and contained.

The minimum CFM requirement for this planer is 600 CFM at the dust port, which means your dust collection system should have a rating greater than 600 CFM, as air friction and leakage reduce effective CFM at the dust port.



IMPORTANT

Running this planer without a dust collection system or using a dust collection system with inadequate suction may cause dust and shavings to accumulate inside the planer. This can damage the machine and cause other hazardous situations. Check your dust collection system regularly to make sure it is not jammed or filled up.

Bench Mounting (Optional)

Mounting this planer on a stable surface prevents it from tipping. Using four 5/16" bolts for mounting provides maximum strength and stability.

Controls and Components

ON / OFF Switches

- To start this planer, lift the power switch paddle.
- To stop, press the paddle down.

NOTICE: This power switch can be locked with a padlock. Lock the power switch to protect unexpected guests from getting injured.



Overload Protection Reset Button

The overload protection button is right next to the power switch. If the planer is overloaded and stopped, the reset button will pop up. Wait for 3 minutes for the machine to cool down. Reduce the workload, then press the reset button before resuming operation.

Depth of Cut Adjustment

Each turn of the headstock handwheel changes the depth of cut by 1/16". Turn clockwise to lower the cutterhead and increase the depth of cut. Turn counterclockwise to raise the cutterhead and reduce the depth of cut.

The spring-loaded knob keeps the handwheel from rolling when it's fully tightened. Untighten the knob by 1-2 turns to allow the handwheel to move.



Feed Rate Selector

10055 Planer can feed stock at 12 or 22 FPM (feet per minute). The high feed rate allows faster processing time for milling stock to approximate thickness. Use the low feed rate to create a fine finish.

To change the feed rate, turn on the planer and wait for the motor to come to full speed, then rotate the selector and set the feed rate.



IMPORTANT


Only change the feed rate when the machine is running at full speed. Failure to do so may cause the gearbox to jam and damage the machine.

Material Removal Gauge

The material removal gauge shows the amount of stock to be removed. The sensor bar is located behind the depth of cut limiter.

Depth of Cut Limiter

This non-moving part protects the motor from overloading by limiting the depth of cut of wide stock to $\frac{3}{64}$ ".



Depth Stops

Allows quick and repeatable adjustments for thickness planing. Five settings are available: $\frac{3}{16}$ ", $\frac{1}{4}$ ", $\frac{1}{2}$ ", $\frac{3}{4}$ ", and 1".

To plane stock to the thickness of the above:

1. Raise the headstock above the desired thickness setting.
2. Rotate the depth stop gauge to the desired thickness setting.
3. Lower the headstock until the positive stop bolt rests on the depth stop gauge.



IMPORTANT

Do not force the headstock to go below the height limited by the depth stop. Permanent planer damage may occur.

Digital Readout (DRO)

This planer is equipped with a DRO that shows the current thickness settings so the operator can adjust the height of the headstock and plane the workpiece to the desired thickness.

This DRO has a resolution of 0.005" or 0.05mm.

The DRO display turns off if the thickness setting remains unchanged for 5 minutes. It will turn back on when the headstock position changes or when someone presses any buttons on the DRO.

When the planer is connected to the power, the DRO stores the current value when it remains unchanged for 2 seconds. The DRO displays "----" when it saves the value. The saved value persists even when the planer is cut off from power. However, the DRO won't register headstock position changes without power. Therefore, it is recommended to recalibrate the DRO each time the planer reconnects to a power source to ensure proper thickness settings of the DRO.



DRO Controls


| | |
|--------------------------------------|---|
| Display Button | Press this button to turn on/off the display. |
| IN/MM Button | Toggle measuring unit between metric (mm) and US standard (inch). |
| ABS Zero Button | Short press to set the display value to 0 and use the DRO to measure the offset between thickness settings. Long press to set the value to 0.185. This function is to reset the value to the minimum distance between the planer table and the cutterhead (see "DRO Calibration" below). |
| Stock Removal Indicator Light | This light turns on when the DRO displays a value less than zero. |

DRO Calibration

1. Rotate the depth stop to the 3/16" position. This is the planer's minimum thickness setting.
2. Lower the headstock until the depth positive stop bolt rests on the depth stop.
3. Long press the "ABS Zero" button for 2 seconds, and the value of the DRO should reset to "0.185", which matches the depth stop settings.
4. The DRO will stay calibrated unless the user short-presses the "ABS Zero" button and sets the value to zero.

Components for Planing Wood

This diagram shows the components involved in planing a piece of wood:



How it works:

1. As a workpiece enters the planer, the anti-kickback fingers **[A]** engage the workpiece to prevent accidental kickback.
2. When the workpiece enters the planer, the infeed roller **[B]** pulls the workpiece towards the cutterhead **[C]**.
3. Cutterhead then planes the workpiece to the desired thickness.
4. Wood chips and dust generated by the cutterhead are collected by the chip breaker **[D]** and diverted toward the dust shroud **[E]**.
5. As the workpiece moves past the cutterhead, the outfeed roller **[F]** pulls the workpiece away from the planer.

Test Run

To familiarize yourself with this planer and ensure everything is well-calibrated, you are advised to run the following tests before commencing production work.

Step 1: Verify all electrical components are functional.

1. Remove all tools and debris from the planer table and the extension tables.
2. Make sure the power switch is in the OFF position.
3. Connect the machine to the power source.
4. Make sure the DRO is turned on.
5. Flip the power switch to ON. The planer should start running with no excessive vibration or noise.
6. Flip the power switch to OFF to stop the machine.

Step 2: Verify that the planer is functional and calibrated.

1. Connect the planer to a dust collection system.
2. Move the headstock to the lowest position. The headstock should stop at the 3/16" mark as shown on the manual thickness scale or the height set by the depth stop.
3. Raise the headstock all the way up. It should stop approximately at the 6" mark on the manual thickness scale.
4. Ensure all anti-kickback fingers can move freely.
5. Observe the DRO readings. It should reflect the movements of the headstock.
6. Prepare a piece of good quality, straight-grain wood board with a flat bottom for a test run. It is advised to choose a board that is close to 15" wide and at least 2 feet long.
7. Start the dust collection system.
8. Set the depth of cut to approximately 3/64" for a test pass.
9. Turn on the dust collection system and the planer, then begin feeding the workpiece. The feed rollers should pull the workpiece through the planer. Verify the entire top surface is planed.
10. Turn off the planer and dust collection system, then inspect the workpiece for any defective finish.
11. Using a caliper, check that the workpiece thickness is uniform side-to-side and front-to-back. This ensures the cutterhead is parallel with the planer table.
12. Check the manual thickness scale. It should point at the same value as shown on the caliper.
13. Check for excessive snipe. A minimum amount of snipe may occur at the ends of the board, and it is expected.

Congratulations! You have completed the test run, and your planer is ready for production work. If you discover any issues from the tests, please refer to the troubleshooting section and maintenance section to diagnose issues and make adjustments.

Accessories

Oliver Machinery has a collection of accessories for your planer. Please visit our website, **OLIVERMACHINERY.NET**, to purchase these items.

You may also call **1-800-559-5065** or email **PARTS@OLIVERMACHINERY.NET** to purchase these items. We are available Monday through Friday, 7:30 AM - 4 PM Pacific Time.



WARNING

Using unapproved accessories may cause the machine to malfunction, resulting in serious injury and/or machine damage. Only use accessories recommended for this machine.

Cutter Inserts



Genuine HCX four-sided indexable carbide cutter inserts compatible with the Oliver **10055 Planer**. Sold in box of 10.

Part numbers:

Cutter Inserts (Box of 10) - **P-15mm4S**

Torx Screws - **038201-101**

Mobile Tool Stand



Need to move the planer around the shop? This tool stand comes with a pre-drill table top for mounting the planer, an ergonomic height-adjustable metal frame, and four heavy-duty locking swivel casters. The casters are equipped with leveling rubber feet to keep the planer stationary even on an uneven floor.

Part number: **A-ADJSTAND.001**

Please visit our website at **WWW.OLIVERMACHINERY.NET/ACCESSORIES** for other recommended accessories.

Operation

For safety and to achieve the best results, please take the following steps before processing any workpiece with this planer.

Step 1: Preparation

Only Use Natural and Quality Wood

Only plane good quality natural wood materials. Cracked stock, boards with loose knots, plywood, and other engineered wood products can break apart and cause severe kickbacks, which can lead to severe injuries and machine damage.

Do not plane treated lumber or anything that contains harmful chemicals, as this will spread wood dust that contains such harmful chemicals.

NEVER plane boards that are shorter than 8", as mentioned in the specifications.

Inspect the Workpiece

Carefully inspect the workpiece for foreign objects. Nails, staples, rock chips, and other objects embedded on the wood surface will damage the planer. To avoid chipping or dulling the cutter inserts, clean the workpiece with a stiff brush to remove all dirt and foreign objects before planing, especially for rough-sawn or reclaimed lumber. Use a metal detector to scan for metal objects as needed.

Check Moisture Content

Check the moisture content of stock before the operation. "Green wood" with moisture content over 20% will not cut properly and may jam the machine. Excessive moisture content can also cause the planer's unpainted surface to rust. Besides, as the workpiece dries, the once-flattened surface can become fuzzy and warped again. Allowing a workpiece to dry and stabilize before it is processed is recommended.

Warped Stock

Boards with moderate cupping, bowing, or twisting should have one side face-jointed before being processed by a planer. It is acceptable to process a slightly cupped board. Make sure the concave side is facing down, and begin with light cuts.


Avoid using boards that are severely warped, as they can be unstable and might cause severe kickbacks during operation.

Glue Deposits

Glue left on the workpiece surface can dull cutters and impact cut quality. Scrape off all glue deposits from the workpiece before the operation.

Wood Grain Direction

This planer is designed to plane WITH the grain direction of the wood. Do not plane cross-grain or end-grain. Severe kickback and chipping may occur.




Step 2: Setting the Depth of Cut

Each rotation of the headstock handwheel changes the depth of cut by 1/16". To make small and repeatable depth of cut adjustments, use the DRO. The manual thickness scale provides a quick view of the cutterhead's position, and the depth stop provides five thickness presets.

This planer can remove at most 1/8" of materials per pass. For stocks that are over 6-1/2" wide, the planer can remove at most 3/64" of materials per pass. The depth of cut limiter limits the depth of cut of wide stock. To plane narrow stock with a greater depth of cut, feed the stock on either side of the planer table and avoid the limiter.

When a workpiece is fed slightly past the limiter, the material removal gauge shows the amount of material to be removed. Take light passes and reduce the feed rate when approaching the desired thickness.




Wood Hardness

Reduce the maximum depth of cut for wood types that are extremely hard or extremely soft. Hardwood increases the planer's workload, and very soft wood species may get a poor finish when receiving aggressive cuts.


The Janka scale shows the hardness of wood types that are commonly used. It ranks the hardness of various wood types by measuring the amount of force (in lbs.) required to embed a 0.444" steel ball halfway into the wood.

Janka Wood Hardness Scale



Maximum Depth of Cut

Based on Douglas Fir hardness. Harder woods and wider stock require more passes to remove the same amount of material.




3" width boards 1/16" max cut depth
6" width boards 1/32" max cut depth
13" width boards 1/64" max cut depth


Step 3: Determining the Feed Direction

Inspect the workpiece and identify the direction of the edge grain. Choose a feed direction such that cutters will cut **WITH** grain to minimize tearouts.

Good – Planer cuts **WITH** the grain.



Not Ideal – Planer cuts **AGAINST** the grain.



Sometimes, it is impossible to cut with the grain for the entire length of a workpiece. In this case, try feeding the workpiece in the opposite direction and see what works best. Reducing the depth of cut can also help improve cut quality.

Step 4: Planing Wood to Desired Thickness

With the above preparation steps completed, the workpiece is ready for planing.



WARNING

Always wear goggles and other protective devices when operating this machine. Stay on the side of the planer to avoid kickback-related accidents. NEVER look inside the planer during operation. Failing to comply may result in serious injuries or death.



CAUTION

Use an ear protection device to prevent hearing loss. Ensure the dust collection system is functional, and use a dusk mask to avoid inhaling harmful airborne particles.

1. Put on protection devices.
2. If you have a long workpiece, make sure it is properly supported throughout the process. Bolt down the planer on a stable surface as needed.
3. Measure the workpiece thickness and set the initial depth of cut to no more than 1/32". This allows feed rollers to properly engage the workpiece and not remove too much material for a test pass.
4. Turn on the dust collection system and planer.
5. While standing on the side of the workpiece, gently feed the workpiece with the face jointed side down. Once the infeed roller engages the workpiece, allow the machine to feed the workpiece. **DO NOT** force feed the workpiece through the planer.

If the infeed roller does not engage the workpiece:

- The headstock height is set too high.
- Stop the machine and wait for it to come to a complete stop, then raise the headstock to remove the workpiece.
- Lower headstock height and restart from step 4.

If the machine stalls or the workpiece gets stuck:

- The headstock height is set too low.
 - Stop the machine and wait for it to come to a complete stop, then raise the headstock to remove the workpiece.
 - Reduce the depth of cut, and restart from step 4.
6. If the workpiece is feeding properly, wait until the entire workpiece clears the outfeed roller, then remove the workpiece. Support the workpiece as it exits the planer.
 7. After the initial pass, measure the workpiece thickness in the midsection.

If more material needs to be removed, continue with the following steps.

8. If you need to remove a lot of material, run a few passes with deeper cuts, then finish with a light pass.
9. The depth of cut for each pass should be less than 1/8". For workpieces 6-1/2" or wider, the depth of cut is limited to 3/64". Reduce the maximum depth of cut for harder wood types. Use DRO to adjust the depth of cut.
10. Repeat until the workpiece has reached the desired thickness.

Turn off the planer when the work is completed.

Common Wood Planing Problems

Snipe


When a workpiece is not properly supported as it enters or leaves the machine, the ends of the workpiece will have more materials removed than the rest of the section. To mitigate this problem, hold the workpiece up slightly as it enters and leaves the machine. Sometimes, a small amount of snipe is inevitable. The best way to eliminate snipe completely is to prepare a workpiece of extra length and then trim the ends when the planing is done. You can also try adjusting the the outside edges of the infeed and outfeed tables to above level 1mm at a time, see page 34.



Chipping

Happens when cutting against the grain direction. See "**Select Feed Direction**" in this section. For highly figured lumber and areas near a knot, some amount of chipping is normal. In this case, moistening the problematic area before planing can sometimes mitigate the issue.

Chipping can also be caused by dirty or dull cutters. If chipping happens while planing straight grain stocks, inspect cutter inserts and remove all resin buildups. Rotate/replace dull cutter inserts when they are dull.



Indentation

This can happen when some foreign object is pressed on the workpiece when it passes through the planer. Remove all resin buildups from the rollers, cutterhead, and table. Also, check the dust collection system and ensure wood chips are effectively removed.

Grooves or ridges along the plane direction

Check the cutter inserts to make sure they are not shifted, chipped, or destroyed.

Fuzzy Grain

This can happen when planing wood with high moisture content or if the cutter is dull. Sometimes, this is unavoidable due to the nature of certain wood types. To mitigate this issue, avoid using wood with high moisture content and use sharp cutters.

Maintenance

Routine maintenance keeps your planer in top shape. Please follow the maintenance schedule below and use the maintenance record worksheet in the manual to document all tasks completed.

NOTICE: Maintenance schedule may vary for individual users due to different situations and safety requirements.



WARNING

Disconnect the machine from the power source before any maintenance work is performed. After servicing the planer, remove all wrenches and tools before restarting the machine. Failure to comply can cause serious injury!

Maintenance Schedule

| Interval | Task |
|----------------|---|
| Every day | Remove dust buildups from the planer. |
| | Inspect the power cord and plug for signs of aging and damage. Replace as needed. |
| Every week | Inspect cutterhead, rollers, and anti-kickback fingers. Remove any dust and resin accumulation. |
| | Inspect/rotate/replace worn cutter inserts. |
| | Wax planer table and extension tables. |
| Every 6 months | Inspect the elevation of the extension tables. Adjust as needed. |
| | Inspect the poly V-belt and replace it if it shows signs of cracking or glazing. |

Notice: Motor bearings are permanently sealed and lubricated and do not require lubrication.

Rotate/Replace Cutter Inserts



CAUTION

Cutter inserts are extremely sharp. Protect your hands with thick leather gloves to avoid injuries.

1. **Disconnect the planer from the power source!!**
2. Remove the dust shroud.
3. Remove the cutterhead cover screws with a 4mm hex wrench.



4. Remove dust and resin accumulations on the cutterhead and areas nearby.



5. Use a 4mm hex wrench to manually rotate the cutterhead and inspect the cutter inserts.



6. Rotate cutter inserts 90° clockwise when they get dulled or nicked.
7. To rotate/replace a cutter insert, remove the Torx screw with a T-25 Torx bit. Turn **COUNTERCLOCKWISE** to loosen the screw.

8. With the cutter insert removed from its seat, thoroughly clean the seat with a vacuum.



IMPORTANT: Obstacles between the insert and its seat will create uneven pressure against the insert. This will impact cut quality and may cause the insert to break.

9. Inspect the Torx screw. Replace any damaged screws. Lubricate screw thread with a thin coat of lightweight machine oil or anti-seize.

IMPORTANT: Do not apply an excessive amount of lubrication, or the Torx screw and the cutter insert will not sit properly.

10. Reinstall the cutter insert with the Torx screw and the marked cutting edge facing out. Secure the cutter insert with 55 lbs.-inch of torque. Use a torque wrench to tighten the screws if one is available.

IMPORTANT: Do not overtighten the screw, or the inserts may break. Do not use power tools to tighten the Torx screws, as it can strip the screws.

11. Reinstall the cutterhead cover and dust shroud after servicing the cutterhead.

Inspect / Replace Poly V-Belt

1. **Disconnect the planer from the power source!!**
2. The drive belt of the planer is located behind the right panel. To access the drive belt, begin by removing the headstock handwheel and the three screws marked in the picture.



3. Loosen these four screws on the front panel.




4. Temporarily open the front panel and remove the two socket cap hex screws behind the panel.




TIP: Take a picture of the back of the panel to keep track of the wiring, so the wires can be easily reattached when needed.



5. Reattach the front panel, then lift the right side of the top panel to expose both motor and cutterhead pulleys. Be careful not to damage any exposed electrical wires.



6. Inspect the drive belt for signs of wear and tear. Replace the belt as needed.
7. To replace the drive belt, walk the old belt away from the motor pulley, then remove the belt from the cutterhead pulley and slip the belt through the openings.
8. Reverse the previous step to install the new belt. A new belt can be very tight, so walk the belt back to the pulleys one groove at a time on the motor pulley. Refrain from using sharp tools to pry the belt back in place, as it may damage the new belt and pulleys.



9. Rotate the pulleys and make sure the drive belt is fully seated into the grooves of the pulleys.
10. Reverse steps 2-5 to re-install the top cover, front panel, right panel, and handwheel after servicing the belt.

Inspect / Adjust Extension Tables

The extension tables should be adjusted so that they are level with the planer's main table.

To Adjust the Extension Tables

1. **Disconnect the planer from the power source!!**
2. Place a long straight edge that spans across the planer table and the extension tables. Adjust the tables to be level on the left and right side and secure adjustment screws.



3. If adjustment is needed, loosen the extension table mounting screws and adjust the extension tables. Tighten the mounting screws after the adjustments.




The left and right side of both extension tables should be flush with the main table.

To Adjust for Potential Snipe

When planing heavy stock, the weight of the stock may cause the extension tables to dip below the planer table causing snipe. If this happens, raise outer edges of the extension tables in 1mm increments up to 3mm.

1. **Disconnect the planer from the power source!!**
2. Using pennies or flat washers as a reference under the straight edge on the main table.

There should be a gap formed between the straight edge and the planer's main table. Inside edges should be level, outside edges can be lifted slightly in approximately 1mm increments as needed.



3. The straight edge should rest on the outside edge of the extension tables while leaving a 1mm gap between the straight edge and the main table.

Adjust Cutterhead Height Scale

The cutterhead height scale is pre-calibrated in the factory. It can be re-adjusted to accommodate a different viewing angle or if the pointer is shifted.

1. Prepare a piece of scrap board with a flat bottom for calibration.
2. Plane the board down to the desired thickness. Use a caliper to measure the mid-section of the board for thickness.
3. Loosen the screws that hold the pointer in place.



4. Shift the pointer so it is pointing at the exact value of the thickness of the board.
5. Re-tighten the screws.

Depth Stop Positive Stop Adjustment

1. Prepare a scrap board that is slightly over one of the depth stop's presets (3/16", 1/4", 1/2", 3/4", 1").
2. Rotate the depth stop to the desired position. For instance, dial the depth stop to 1" when using a 1-1/8" scrap board for adjustments.
3. Lower the headstock until it rests on the depth stop.
4. Switch the DRO to incremental mode and make sure the value is zeroed. This value indicates the original position of the headstock. Do not reset this value until completing the adjustments steps.
5. Plane the scrap board. Use a caliper to measure the thickness of the midsection of the board. The measurement should match the depth stop's preset.
6. If the measurement is different from the preset, adjustment is necessary. Calculate the difference, then loosen the jam nut and slightly back off the positive stop nut.



7. Use the DRO to adjust the headstock position to compensate for the error.
8. Hand rotates the positive stop nut so it presses against the depth stop, then holds the nut in place and tightens the jam nut.
9. Plane another scrape board to verify the adjustments. Repeat the adjustment steps as needed.

Anti-Kickback Fingers Inspection

This planer is equipped with anti-kickback fingers. Once engaged, the workpiece can only move toward the cutterhead. This safety device prevents accidental kickbacks, which can cause serious injuries.



Inspect the anti-kickback fingers regularly to ensure they can move freely. Make sure their claws are clean and sharp enough to stop a board from moving backward. Clean and apply a very light coat of SAE-30 machine oil as needed to prevent rust.

Replace anti-kickback fingers if they are damaged or worn.



CAUTION

Do not operate this planer without functioning anti-kickback fingers. Failure to comply can result in serious injury.

Troubleshooting

Mechanical / Electrical Issues


| Problem | Possible Cause | Possible Solution |
|--|---|---|
| Machine does not start. | Machine is not connected to a power source. | <ol style="list-style-type: none"> 1. Make sure the machine is plugged in. 2. Check the electrical panel for a tripped circuit breaker or a blown fuse. 3. Ensure all electrical connections have good contacts. |
| | Low voltage/current. | <ol style="list-style-type: none"> 1. If an extension cord is used, use a shorter/heavier extension cord. 2. Have an electrician to check/repair the power circuit. |
| | Overload protection triggered. | Press the overload protection reset button to reset. |
| | Faulty switch/motor. | Contact customer service for further assistance. |
| Machine trips thermal protection/circuit breaker or blow fuses. | Machine is undersized for the operation. | Reduce the depth of cut. |
| | Workpiece moisture level is too high. | Only plane wood with moisture level below 20%. |
| | Machine is jammed. | Inspect the cutterhead and make sure it is not obstructed by woodchips. Check dust shroud and clear blockages. |
| | Too much load on a circuit. | Make sure the power circuit is sized for this machine. If the circuit is shared, ensure it is sized to supply power for all items in the circuit. |
| | Motor issue. | Contact customer service for further assistance. |
| Machine stalls during operation. | Machine is undersized for the operation. | Reduce the depth of cut. |
| | Dull cutters. | Rotate/replace cutter inserts. |
| | Belt slipping. | Clean belt and pulleys. Replace the belt as needed. |
| | Motor issue. | Contact customer service for further assistance. |
| Machine stopped during operation. | Overload protection triggered. | Hit the OFF button and allow the machine to cool down for at least 3 minutes, then press the overload protection reset button. Reduce the depth of cut before resuming work. |
| Digital readout is not functional. | Display is turned off. | Press any button on the DRO to reactivate the display. |
| | Malfunctioning circuit board. | Contact customer service for further assistance. |

| Problem | Possible Cause | Possible Solution |
|--|---|--|
| Workpiece does not feed smoothly. | Dirty planer table/feed rollers. | Clean table and rollers. Apply paste wax on the planer table and extension tables to reduce drag. Do not use silicone lubrication. |
| | Belt slipping. | Clean belt and pulleys. Replace the belt as needed. |
| Machine vibrates excessively or makes unexpected noise. | Damaged cutter inserts. | Replace cutter inserts. |
| | Machine stands on an uneven surface. | Reposition on a flat, level surface. |
| | Drive belt worn, slipping, or hitting belt cover. | Clean belt and pulleys. Replace the drive belt if it shows signs of aging. |
| | Loose components. | Tighten the fasteners of the component. |
| Board thickness does not match the scale's measurement. | Manual thickness scale pointer is mispositioned. | Adjust the scale. |
| | DRO is not calibrated. | Re-calibrate the DRO. |
| | Depth stop's positive stop is mispositioned. | Adjust the positive stop. |
| Unable to turn headstock handwheel. | Headstock is stopped by depth stop. | Adjust the depth stop's minimum height setting. Minimum cutterhead height is 5/32". |
| | Handwheel knob is fully tightened. | Loosen the knob by 1-2 turns. |

Finish Quality Issues

| Problem | Possible Cause | Possible Solution |
|--|---|---|
| Workpiece came out twisted. | Workpiece is twisted before the cut. | Planer is not the tool to flatten a twisted workpiece. Flatten one side with a jointer before proceeding with a planer. |
| Excessive snipe. | Extension wing slope down. | Adjust extension table elevation. |
| | Long workpiece is not supported properly. | Use auxiliary rollers to support the long workpiece. |
| | A small amount of sniping can happen sometimes. | Add an extra 6" length on a workpiece for planing, and then trim off the ends. |
| End of workpiece chipping. | Aggressive depth of cut for the wood type. | Reduce the depth of cut. |
| | Planing end grain. | Do not plane end grain. Use a drum sander instead. |
| Chipping in workpiece surface. | Dull or damaged cutter. | Rotate/replace cutter insert. |
| | Planing against/across grain or knots. | Avoid planing workpieces with knots. Plane with grain whenever possible. Moisten problematic areas before planing. |
| | Too much material was removed in one pass. | Reduce the depth of cut. |
| Indentation in workpiece surface. | Dirty rollers. | Remove all buildups on infeed and outfeed rollers. |
| | Inefficient chip removal. | Check the dust collection system for suction. |
| Fuzzy-looking finish. | Wood moisture content is too high. | Only process wood with less than 20% moisture content. |
| | Dull cutter. | Rotate/replace cutter insert. |
| | Some wood types tend to have fuzzy grain. | Adjust the depth of cut. Use sharp cutters. |
| Glossy-looking finish. | Dull cutter. | Rotate/replace cutter insert. |
| | Cutting depth too shallow. | Increase the depth of cut. |
| Long lines or ridges run along the length of the board. | Chipped or incorrectly installed cutter. | Rotate/replace cutter insert. |


Wiring Diagram




Top Cover




Motor and Cutterhead



Head Casting



Base



| Key | Part Number | Description | Specification | QTY |
|-----|-------------|---|------------------------|-----|
| 1 | 000801-102 | Round Head Hex Screw | M6*1.0P*12 | 10 |
| 2 | 175335-904 | Roller Bracket | | 2 |
| 3 | 250251-615 | Bushing | | 2 |
| 4 | 361543-901 | Roller Shaft | | 1 |
| 5 | 190331-906 | Roller | | 1 |
| 6 | 008304-100 | Locking Nut | M6*1.0P | 4 |
| 7 | 361542-906 | Support Rod | | 1 |
| 8 | 006003-009 | Flat Washer | 5.2*10*1.0t | 2 |
| 9 | 002002-101 | Round Head Phillips Screw | M5*0.8P*8 | 2 |
| 10 | 251546-615 | Dust Chute | | 1 |
| 11 | 230452-000 | Knob | M6*12L | 4 |
| 12 | 175325-008 | Dust Hood | | 1 |
| 13 | 000303-102 | Round Head Screw | M5*0.8P*8 | 4 |
| 14 | 006502-100 | Teeth Washer | 5.3*10(BW-5) | 3 |
| 15 | 175330-000 | Grounding Plate | | 1 |
| 16 | 001201-804 | Self Tapping Screw | M4*1.41P*8 | 6 |
| 17 | 001201-801 | Self Tapping Screw | M4*1.41P*12 | 5 |
| 18 | 250658-615 | Switch Cover | | 1 |
| 19 | 830014-001 | Safety Switch Assembly | | 1 |
| 20 | 175323-904 | Front Cover | | 1 |
| 21 | 924567-001 | Overload Switch Assembly | 14AMP(220V-240V) | 1 |
| 22 | 251530-000 | Top Cover | | 1 |
| 23 | 001702-101 | CAP Screw w/Flat Washer | M5*0.8P*60-5.3*12*1.0t | 2 |
| 24 | 925317-000 | T Wrench | T25 | 1 |
| 25 | 001602-106 | Round Head Phillip Screw w/Flat Washer | M5*0.8P*15/5*12*0.8t | 2 |
| 26 | 000302-102 | Round Head Phillips Screw | M4*0.7P*8 | 4 |
| 27 | 251532-615 | DRO Cover | | 1 |
| 28 | 491289-000 | DRO | | 1 |
| 29 | 008005-100 | Hex. Nut | M6*1.0P | 4 |
| 30 | 010602-000 | Retaining Ring | CRTW-12 | 4 |
| 31 | 021103-100 | Cable Clamp | ACC-3-B | 2 |
| 32 | 020203-000 | Strain Relief | SR11-2(HEYCO) | 1 |
| 33 | 000304-103 | Round Head Screw | M6*1.0P*12 | 7 |
| 34 | 251528-615 | Side Cover-L | | 1 |
| 35 | 320426-000 | Worm Shaft | | 1 |
| 36 | 010106-000 | Retaining Ring | RTW-42 | 1 |

| Key | Part Number | Description | Specification | QTY |
|------|-------------|---|---------------------------|-----|
| 37 | 030214-002 | Ball Bearing | 6004 | 1 |
| 38 | 925325-001 | Helical Cutterhead Assembly | with 40 inserts | 1 |
| 39 | 012004-001 | Key | 6*6*20 | 1 |
| 40 | 130094-903 | Locking Nut | | 3 |
| 41 | 170746-901 | Lock Washer | | 4 |
| 42 | 150016-000 | Sprocket | | 4 |
| 43 | 250413-615 | Dustproof Sheet | | 4 |
| 44 | 920133-000 | Bearing | | 8 |
| 45 | 300039-000 | Lead Screw Seat | | 3 |
| 46 | 012001-003 | Key | 3*3*10 | 5 |
| 47 | 280083-901 | Spring | | 4 |
| 48 | 130090-000 | Backlash Nut | | 4 |
| 49 | 000102-814 | Socket Head Cap Screw | M5*0.8P*44.3 | 8 |
| 50 | 016231-000 | Chain | #410-140P | 1 |
| 51 | 000303-803 | Round Head Screw | M5*0.8P*10 | 25 |
| 52 | 170753-901 | Plate | | 1 |
| 53 | 002402-101 | Round Head Phillips Lock Screw w/washer | M5*0.8P*12/5*10*1.0t | 6 |
| 54 | 925320-000 | Lift Tension Wheel Assembly | | 1 |
| 55 | 170292-901 | Fixing Plate | | 2 |
| 56 | 090403-008 | Head Casting | | 1 |
| 57 | 491290-000 | Buckle | | 1 |
| 58 | 000301-111 | Round Head Screw | M3*0.5P*4 | 2 |
| 59 | 175331-000 | Sensing Piece | | 1 |
| 60 | 130428-903 | Nut | | 1 |
| 61 | 901399-000 | Motor Assembly with Key | 2.5HP*1Ph*230V*60HZ | 1 |
| 61.2 | 496346-000 | Running Capacitor | 30UF/450VAC(LAI)(50*90.5) | 1 |
| 61.3 | 012202-009 | Key | 5*5*25 | 1 |
| 62 | 090407-000 | Motor Pulley | | 1 |
| 63 | 006002-212 | Flat Washer | 6.5*30*3t | 2 |
| 64 | 002602-103 | Cap Locking Screw | M6*1.0P*16 | 1 |
| 65 | 251551-615 | Belt Cover | | 1 |
| 66 | 001602-101 | Round Head Phillips Screw & Flat Washer | M5*0.8P*10/5*12*0.8t | 2 |
| 67 | 048902-104 | CAP Lock Screw w/Spring Washer | M5*0.8P*12L-5.1*9.3*1.3t | 2 |
| 68 | 175406-000 | Motor Bracket | | 1 |

| Key | Part Number | Description | Specification | QTY |
|-----|-------------|--|---------------------------------|-----|
| 69 | 001501-101 | CAP Screw w/Spring Washer & Flat Washer | M8*1.25P*20/8.2*13.7/8.5*19*2t | 1 |
| 70 | 002601-110 | Cap Locking Screw | M8*1.25P*30 | 2 |
| 71 | 010109-000 | Retaining Ring | RTW-62 | 1 |
| 72 | 030210-002 | Ball Bearing | 6206 | 1 |
| 73 | 090408-000 | Cutter Head Pulley | | 1 |
| 74 | 002501-805 | Round Head Hex. Lock Screw | M6*1.0P*16 | 5 |
| 75 | 014383-000 | Poly-V-Belt | | 1 |
| 76 | 175424-904 | Inner Chip Guard | | 1 |
| 77 | 000204-103 | SET Screw | M8*1.25P*12 | 1 |
| 78 | 280052-000 | Spring | | 2 |
| 79 | 017002-000 | Steel Ball | Ø6 | 2 |
| 80 | 049901-001 | CAP Lock Screw w/Spring Washer & Flat Washer | M6*1.0P*15/6.5*10.5/6.2*13*1.5t | 1 |
| 81 | 251527-615 | Knob | | 1 |
| 82 | 925387-000 | Gear Lever Assembly | PJ42 | 1 |
| 83 | 006702-100 | Wavy Washer | WW-8 | 1 |
| 88 | 175426-000 | Depth Scale | | 1 |
| 89 | 000301-101 | Round Head Screw | M3*0.5P*6 | 4 |
| 90 | 921977-000 | Depth Pointer | | 1 |
| 91 | 048101-101 | Round Head Phillips Screw w/Spring Washer | M5*0.8P*10-5.1*9.3*1.3t | 2 |
| 92 | 175326-156 | Pointer | | 1 |
| 93 | 008004-100 | Hex. Nut | M5*0.8P | 1 |
| 94 | 000001-109 | Hex. Screw | M5*0.8P*12 | 1 |
| 95 | 010014-000 | Retaining Ring | STW-35 | 2 |
| 96 | 320227-000 | Gear | | 1 |
| 97 | 300038-000 | Main Lead Screw Seat | | 1 |
| 98 | 160019-000 | Copper Bushing | | 1 |
| 99 | 320234-901 | Gear (s) | | 1 |
| 100 | 030113-001 | Ball Bearing | 6001ZZ(A) | 1 |
| 101 | 010112-000 | Retaining Ring | RTW-28 | 1 |
| 102 | 251529-615 | Side Cover-R | | 1 |
| 103 | 090405-008 | Handwheel | | 1 |
| 104 | 251533-615 | Knob | | 1 |
| 105 | 360302-901 | Knob Shaft | | 1 |

| Key | Part Number | Description | Specification | QTY |
|-------|-------------|--|-------------------------|-----|
| 106 | 250262-615 | Knob Cover | | 1 |
| 107 | 925385-001 | Lock Handle Assembly | | 1 |
| 107.1 | 006001-091 | Flat Washer | 13*28*3.0t Black | 1 |
| 107.2 | 280134-000 | Compression Spring | | 1 |
| 107.3 | 006001-036 | Flat Washer | 6.7*19*2.0t Black | 1 |
| 107.4 | 230453-000 | Knob | M6x50L | 1 |
| 108 | 925388-001 | Limited Plate | PJ42 | 1 |
| 109 | 048101-102 | Round Head Phillips Screw w/Spring Washer | M5*0.8P*16-5.1*9.3*1.3t | 2 |
| 112 | 250060-615 | Spacer | | 38 |
| 113 | 170165-905 | Anti-Kickback Plate | | 39 |
| 114 | 006001-024 | Flat Washer | 6.4*12*1.5t | 6 |
| 115 | 002602-106 | Cap Locking Screw | M6*1.0P*25 | 2 |
| 116 | 361339-902 | Shaft for Anti-Kickback Plate | | 1 |
| 117 | 280084-901 | Roller Spring | | 4 |
| 118 | 130089-000 | Roller Bushing | | 4 |
| 119 | 660001-000 | Packing | | 4 |
| 120 | 340144-000 | Outfeed Roller | | 1 |
| 121 | 010006-000 | Retaining Ring | STW-15 | 2 |
| 122 | 380257-901 | Chain Sprocket | | 4 |
| 123 | 170623-902 | Roller Bushing Bracket | | 4 |
| 124 | 340143-000 | Infeed Roller | | 1 |
| 125 | 048602-101 | Round Head Hex. Screw w/Washer | M6*1.0P*10L*19*2t | 2 |
| 126 | 175328-904 | Cover | | 2 |
| 127 | 016232-000 | Chain | #410-34P | 1 |
| 128 | 016214-000 | Chain | #410-30P | 1 |
| 129 | 290028-901 | Shoulder Screw | | 2 |
| 130 | 280082-000 | Tension Spring | | 2 |
| 131 | 920145-001 | Tension Wheel Assembly-L | | 1 |
| 132 | 006001-010 | Flat Washer | 5.2*12*1.5t | 1 |
| 133 | 006001-100 | Flat Washer | 15.5±0.1*21*0.8±0.05 | 1 |
| 134 | 000103-117 | Socket Head Cap Screw | M6*1.0P*85 | 3 |
| 135 | 290029-902 | Tension Shoulder Screw | | 1 |

| Key | Part Number | Description | Specification | QTY |
|--------|-------------|--|------------------------------|-----|
| 136 | 925321-001 | Gearbox Assembly | | 1 |
| 136.01 | 360555-000 | Fixing Pin | | 4 |
| 136.02 | 160019-000 | Copper Bushing | | 3 |
| 136.03 | 006001-100 | Flat Washer | 15.5±0.1*21*0.8±0.05 | 1 |
| 136.04 | 160034-000 | Bushing | | 2 |
| 136.05 | 006001-044 | Flat Washer | 8.5*16*0.8t | 5 |
| 136.06 | 012002-002 | Key | 4*4*7 | 2 |
| 136.07 | 320425-000 | Gear | | 1 |
| 136.08 | 090098-000 | Gearbox | | 1 |
| 136.09 | 320253-000 | Gear | | 1 |
| 136.10 | 320231-000 | Gear | | 1 |
| 136.11 | 925322-000 | Gear Shift Pawl Assembly | | 1 |
| 136.12 | 340048-000 | Packing | | 1 |
| 136.13 | 320233-000 | Gear Shaft | | 1 |
| 136.14 | 170747-000 | Gearbox Cover | | 1 |
| 136.15 | 160033-000 | Bushing | | 1 |
| 136.16 | 360556-902 | Sliding Rod | | 1 |
| 136.17 | 012003-013 | Key | 5*5*40 | 1 |
| 136.18 | 320254-000 | Gear | | 1 |
| 136.19 | 160035-000 | Bushing | | 1 |
| 136.20 | 000303-803 | Round Head Philips Screw | M5*0.8P*10 | 3 |
| 137 | 290030-902 | Shoulder Screw | | 1 |
| 138 | 130091-903 | Gear Wheel | | 1 |
| 139 | 251531-615 | Lead Screw Cover | | 4 |
| 140 | 360553-906 | Shaft | | 4 |
| 142 | 090404-008 | Base | | 1 |
| 143 | 002801-101 | CAP Lock Screw w/teeth Washer & Flat Washer | M8*1.25P*25-7.4*13-8*23*2.0t | 4 |
| 144 | 175329-904 | Scale Bracket | | 1 |
| 145 | 290011-901 | Shoulder Screw | | 1 |
| 146 | 090406-148 | Depth Indicator | | 1 |
| 147 | 001101-203 | Round Head Tapping Screw | M3*1.06P*8 | 2 |
| 148 | 175425-000 | Sensor Bracket | | 1 |
| 149 | 021010-000 | Wire Tie | ALT-150M-B | 1 |
| 150 | 474048-023 | Connect Cord | 24AWG*4C*300mm | 1 |
| 151 | 251509-615 | Sensor Box | | 1 |

| Key | Part Number | Description | Specification | QTY |
|-------|-------------|--|---------------------|-----|
| 152 | 491196-000 | Sensor | CT | 1 |
| 153 | 001106-601 | Round Head Tapping Screw | M2*0.63P*6 | 3 |
| 154 | 381528-902 | Support Shaft | | 1 |
| 155 | 925323-000 | Tension Wheel Assembly-R | | 1 |
| 156 | 000302-116 | Round Head Phillips Screw | M4*0.7P*5 | 4 |
| 157 | 175422-000 | Pressure Plate | | 2 |
| 158 | 340146-615 | Scraper | NBR 、 | 2 |
| 159 | 175423-000 | Scraper Holder | | 1 |
| 160 | 006002-200 | Flat Washer | 4.3*8*0.8t | 2 |
| 161 | 000302-202 | Round Head Phillips Screw | M4*0.7P*8 | 2 |
| 162 | 471037-192 | Connect Cord | 18AWG*1C*350mm | 2 |
| 163 | 471044-037 | Connect Cord | 14AWG*1C*100mm | 1 |
| 164 | 471044-034 | Connect Cord | 14AWG*1C*300mm | 1 |
| 165 | 001601-801 | Round Head Phillips Screw w/Flat Washer | M4*0.7P*8/4*10*0.8t | 1 |
| 166 | 453012-029 | Power Cord w/Plug | 14AWG*3C*2800mm | 1 |
| 167.1 | 575917-000 | Switch Label | | 1 |
| 172 | 925368-000 | Extension Wing Assembly | | 1 |
| .1 | 174683-905 | Extension Wing | | 1 |
| .2 | 174687-905 | Extension Bracket | | 2 |
| .3 | 000801-101 | Round Head Hex Screw | M6*1.0P*10 | 4 |
| .6 | 290112-901 | Shoulder Screw | M8*1.25P | 8 |
| .7 | 040004-000 | Hex Wrench (Local Purchase) | 4*70mm | 1 |
| 182 | 006305-100 | Spring Washer | 8.2*13.7 | 2 |
| 183 | 011102-108 | Pin | 4*12 | 2 |
| 184 | 200126-000 | Sponge | 40*10*20mm(L*W*H) | 2 |

Spare Parts

| Part Number | Description | QTY |
|-------------|--|-----|
| P-15mm4S | Box of 10 - 15mm x 15mm x 2.5t - 4-Sided Carbide Inserts | 5 |
| 038201-101 | Torx Screw for HCX Cutterhead | 5 |

Maintenance Record

| Date | Task | Operator |
|------|------|----------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

[illegible]

Warranty and Service

Oliver Machinery makes every effort to assure that its equipment meets the highest possible standards of quality and durability. All products sold by Oliver Machinery are warranted to the original customer to be free from defects for a period of two (2) years on all parts excluding electronics and motors which are warranted for one (1) year from the date of shipment. Oliver Machinery's obligation under this warranty shall be exclusively limited to repairing or replacing products or parts or components, at its sole option, determined by Oliver Machinery to be defective. Oliver Machinery shall not be required to provide other form of indemnity or compensation including but not limited to compensatory damages.

This warranty does not apply to defects due to direct or indirect misuse, abuse, negligence, accidents, unauthorized repairs, alternation outside our facilities, lack of maintenance, acts of nature, or items that would normally be consumed or require replacement due to normal wear and tear.

OTHER TERMS

To obtain and exercise the warranty right, please call 800-559-5065 or fill out warranty request form online at www.olivermachinery.net.

Warranty parts are shipped via Parcel or Ground. Additional charges will occur and charge to customers if express shipping is required.

DISCLAIMER

Under no circumstances shall Oliver Machinery be liable for death, personal or property injury, or damages arising from the use of its products.

Oliver Machinery reserves the right to make changes without prior notice to its products to improve function or performance or design.

FOR MORE INFORMATION

If you need assistance or have questions beyond what is covered in the scope of this warranty information, please call 800-559-5065 or email us at info@olivermachinery.net.

Appendix

US Standard – Metric Conversion Chart

| Fractions | Decimal In. | Millimeters |
|--------------|-------------|-------------|
| 1/64 | .0156 | .396 |
| 1/32 | .0312 | .793 |
| 3/64 | .0469 | 1.190 |
| 1/16 | .0625 | 1.587 |
| 5/64 | .0781 | 1.984 |
| 3/32 | .0937 | 2.381 |
| 7/64 | .1094 | 2.778 |
| 1/8 | .125 | 3.175 |
| 9/64 | .1406 | 3.571 |
| 5/32 | .1562 | 3.968 |
| 11/64 | .1719 | 4.365 |
| 3/16 | .1875 | 4.762 |
| 13/64 | .2031 | 5.159 |
| 7/32 | .2187 | 5.556 |
| 15/64 | .2344 | 5.953 |
| 1/4 | .25 | 6.350 |
| 17/64 | .2656 | 6.746 |
| 9/32 | .2812 | 7.143 |
| 19/64 | .2969 | 7.540 |
| 5/16 | .3125 | 7.937 |
| 21/64 | .3281 | 8.334 |
| 11/32 | .3437 | 8.731 |
| 23/64 | .3594 | 9.128 |
| 3/8 | .375 | 9.525 |
| 25/64 | .3906 | 9.921 |
| 13/32 | .4062 | 10.318 |
| 27/64 | .4219 | 10.715 |
| 7/16 | .4375 | 11.112 |
| 29/64 | .4531 | 11.509 |
| 15/32 | .4687 | 11.906 |
| 31/64 | .4844 | 12.303 |
| 1/2 | .5 | 12.700 |

| Fractions | Decimals In. | Millimeters |
|--------------|--------------|-------------|
| 33/64 | .5156 | 13.096 |
| 17/32 | .5312 | 13.493 |
| 35/64 | .5469 | 13.890 |
| 9/16 | .5625 | 14.287 |
| 37/64 | .5781 | 14.684 |
| 19/32 | .5937 | 15.081 |
| 39/64 | .6094 | 15.478 |
| 5/8 | .625 | 15.875 |
| 41/64 | .6406 | 16.271 |
| 21/32 | .6562 | 16.668 |
| 43/64 | .6719 | 17.065 |
| 11/16 | .6875 | 17.462 |
| 45/64 | .7031 | 17.859 |
| 23/32 | .7187 | 18.256 |
| 47/64 | .7344 | 18.653 |
| 3/4 | .75 | 19.050 |
| 49/64 | .7656 | 19.446 |
| 25/32 | .7812 | 19.843 |
| 51/64 | .7969 | 20.240 |
| 13/16 | .8125 | 20.637 |
| 53/64 | .8281 | 21.034 |
| 27/32 | .8437 | 21.431 |
| 55/64 | .8594 | 21.828 |
| 7/8 | .875 | 22.225 |
| 57/64 | .8906 | 22.621 |
| 29/32 | .9062 | 23.018 |
| 59/64 | .9219 | 23.415 |
| 15/16 | .9375 | 23.812 |
| 61/64 | .9531 | 24.209 |
| 31/32 | .9687 | 24.606 |
| 63/64 | .9844 | 25.003 |
| 1.0 | 1. | 25.400 |



Oliver Machinery is always adding new Industrial Woodworking products to the line.

For complete, up-to-date product information, visit us online at:

WWW.OLIVERMACHINERY.NET

or call toll free 1-800-559-5065

**** CHECK ONLINE FOR UPDATED MANUALS. ****

**** SAVE THIS MANUAL FOR FUTURE REFERENCES. ****