

Jointer

Model 4265

Owner's Manual

For Models Manufactured Since 06/2019



Oliver Machinery
1-800-559-5065
921 Thomas Ave SW,
Renton, WA 98057

info@olivermachinery.net
WWW.OLIVERMACHINERY.NET

Stock Number: 4265.101.4S
4265.102.4S
Manual Version: 1.0.4



READ AND UNDERSTAND ALL INSTRUCTIONS IN THIS MANUAL BEFORE ATTEMPTING TO ASSEMBLE OR OPERATE THE MACHINE.

FOLLOW THE INSTRUCTIONS AND THINK SAFETY!

THE OWNER OF THIS MACHINE IS SOLELY RESPONSIBLE FOR THE SAFETY OF ANYONE USING THIS MACHINE. SUCH RESPONSIBILITY INCLUDES BUT NOT LIMITED TO:

- **PROPER ASSEMBLY, OPERATION, INSPECTION, MAINTENANCE, AND RELOCATION OF THE MACHINE.**
- **PROPER TRAINING FOR THE OPERATORS AND ENSURES THIS MANUAL IS AVAILABLE AT ALL TIMES.**
- **USAGE AUTHORIZATION.**
- **USAGE OF SAFETY AND PROTECTION DEVICE.**

OLIVER MACHINERY DISCLAIMS ANY LIABILITY FOR MACHINES THAT HAVE BEEN ALTERED OR ABUSED. OLIVER MACHINERY RESERVES THE RIGHT TO EFFECT AT ANY TIME, WITHOUT PRIOR NOTICE, THOSE ALTERATIONS TO PARTS, FITTINGS, AND ACCESSORY EQUIPMENT WHICH THEY MAY DEEM NECESSARY FOR ANY REASON WHATSOEVER.

**** SAVE THIS MANUAL FOR FUTURE REFERENCES. ****

PROP 65 NOTICE

WARNING: Drilling, sawing, sanding, or machining wood products can expose you to wood dust, and/or other chemicals that are known to the State of California to cause cancer, birth defects, or other reproductive harm.

Some examples of these chemicals are:

- Lead from lead-based paints.
- Crystalline silica from bricks, cement, and other masonry products.
- Arsenic and chromium from chemically treated lumber.

Avoid inhaling wood dust and other harmful chemicals. Use a dust mask and/or other safety devices for personal protection.

For more information go to <http://www.P65Warnings.ca.gov/wood>

Table of Contents

| | | | |
|---|-----------|---|-----------|
| Introduction | 6 | Removing Machine from Crate | 20 |
| Specifications | 7 | Cleaning | 20 |
| Quick View | 7 | Assembly | 21 |
| Product Dimensions | 7 | Setup Control Panel | 21 |
| Shipment Info | 7 | Inspect / Adjust Jointer Tables (Optional)..... | 22 |
| Electricals | 7 | Install Cutterhead Guard..... | 22 |
| Motor | 8 | Leveling Machine | 23 |
| Jointer Capacity and Performance | 8 | Dust Collection | 23 |
| Fence | 8 | Wiring and Grounding | 24 |
| Cutterhead | 8 | Wiring Instructions..... | 24 |
| Table | 8 | Controls and Components | 25 |
| Measurements | 9 | Control Panel | 25 |
| Safety | 9 | Infeed Table Height Adjustment Handwheel and Depth Scale | 25 |
| Others | 9 | Infeed Table Depth Stop Knob | 26 |
| Identification | 10 | Outfeed Table Height Lever and Lock | 26 |
| Safety | 12 | Fence | 26 |
| General Safety Guidelines | 12 | Digital Readout (DRO) | 27 |
| Safety Guidelines Specific to Jointer | 13 | DRO Calibration | 27 |
| Electricals | 15 | Test Run | 28 |
| Minimum Circuit Size Required for Model 4265 Jointer | 15 | Operation | 29 |
| Grounding | 15 | Preparation | 29 |
| Electrical Wiring | 15 | Inspect Wood Grain | 30 |
| Setup | 17 | Squaring Stock | 30 |
| Shop Preparation | 17 | Surface Planing | 31 |
| Space Requirement | 17 | Edge Jointing | 33 |
| Load Limits | 17 | Beveling | 33 |
| Electricals | 17 | Rabbet Cutting | 34 |
| Lighting..... | 17 | Common Cutting Problems | 35 |
| Safety Labels | 17 | Snipe..... | 35 |
| Dust Collection | 17 | Chipping | 35 |
| Receiving | 18 | Fuzzy Grain | 35 |
| Moving Machine into the Shop..... | 18 | Accessories | 36 |
| Unboxing | 18 | 460V Conversion Kit | 36 |
| Inventory..... | 19 | Cutter Inserts | 36 |

| | |
|---|-----------|
| Touchup Paint | 36 |
| Power Feeder | 37 |
| Maintenance | 38 |
| Maintenance Schedule | 38 |
| Inspect / Adjust Jointer Tables | 39 |
| Inspect Outfeed Table Height | 39 |
| Adjust Outfeed Table Height | 39 |
| Inspect Outfeed Table Parallelism | 40 |
| Inspect Infeed Table | 40 |
| Adjust Table Parallelism/Coplanarity | 41 |
| Infeed Table Adjustments | 43 |
| Infeed Table Positive Stops Adjustments | 43 |
| Cutterhead Maintenance | 44 |
| Rotate / Replace Cutter Inserts | 44 |
| Adjust Fence Positive Stops | 45 |
| Adjust Belt Tension | 46 |
| Align Belt Pulleys | 47 |
| Troubleshooting | 48 |
| Mechanical / Electrical Issues | 48 |

| | |
|---|-----------|
| Operation / Quality-Related Issues | 49 |
| Wiring Diagram | 51 |
| For Stock # 4265.101.4S (230V, 1Ph) | 51 |
| For Stock # 4265.102.4S (230/460V, 3Ph) | 52 |
| Parts List | 53 |
| Fence Assembly | 53 |
| Table and Cutterhead Assembly | 54 |
| Base Assembly | 55 |
| Motor and Cabinet | 56 |
| Maintenance Record | 66 |
| Notes | 67 |
| Warranty and Service | 68 |
| Appendix | 69 |
| US Standard – Metric Conversion Chart | 69 |

Introduction

Thank you for choosing Oliver! This manual contains important information on how to safely set up, operate, and maintain this machine. Please take the time to read through this manual, and make sure you understand all instructions.

While this manual may provide tips on optimizing the result of your workpiece, the manual is not intended as a substitute for formal woodworking training. If you need to know how to safely complete a woodworking task, please consult knowledgeable and qualified sources before proceeding further.

We made every effort to keep this manual up-to-date. Instructions, specifications, drawings, and photographs in this manual should match the machine delivered. If you find any differences, or anything that seems confusing in this manual, or some instructions are not available, please check our website for an updated version:

WWW.OLIVERMACHINERY.NET/MANUALS

Alternatively, you can contact our technical support for help:


1-800-559-5065

Before calling, please note down the manufacture date and the serial number of the machine. You can find the information on a nameplate located on the back of the machine, right above the electrical junction box. This information is needed to provide proper technical support, and to determine if an updated manual is available for your machine.

Please let us know how well this manual serves you. If you have any suggestions, please call the number above or email us at:

info@olivermachinery.net

We love to hear from our customers and make improvements.



Specifications

Quick View

| | | |
|-------------------------------|---|---|
| Model | 4265 Jointer | |
| Stock Number | 4265.101.4S | 4265.102.4S |
| Motor | Baldor TEFC Induction Motor 3HP, 230V, 1Ph | Baldor TEFC Induction Motor 5HP, 230/460V, 3Ph |
| Jointer Size | 12" | |
| Max. Depth of Cut (Jointing) | 1/8" | |
| Max. Depth of Cut (Rabbeting) | 3/4" | |
| Bevel Joining | 0-45 Degrees | |
| Dimensions | 88-1/2"(L) x 38(W) x 49-1/2"(H) | |
| Footprint | 52-1/2"(L) x 20-1/2"(W) | |
| Fully Assembled Weight | 891 lbs. | |
| Warranty | 1 Year (Motor and electronics) 2 Years (All other parts) | |

Product Dimensions

| | |
|--|----------------------------------|
| Jointer Fully Assembled and Fence Fully Retracted | 88-1/2"(L) x 38"(W) x 49-1/2"(H) |
| Footprint | 52-1/2" (L) x 20-1/2"(W) |
| Fully Assembled Weight | 891 lbs. |

Shipment Info

| | |
|------------------------|-----------------------------------|
| Type | Wood Crate with Pallet Base |
| Content | Jointer with Included Accessories |
| Dimensions | 91" (L) x 31-1/2"(W) x 50"(H) |
| Weight | 1057 lbs. |
| Approximate Setup Time | 60 minutes |
| Must Ship Upright | YES |
| Stackable | NO |

Electricals

| | | |
|--------------------------|---|---------------------|
| Stock Number | 4265.101.4S | 4265.102.4S |
| Power Requirement | 230V, 1Ph, 60Hz | 230/460V, 3Ph, 60Hz |
| Full Load Current Rating | 14.5A | 11.8/5.9A |
| Recommended circuit size | 20A | 15A |
| Power Switch Type | Magnetic switch with overload protection. | |
| Connection Type | Cord and plug not included. Electrical hookups required. | |
| Overload Protection | Equipped | |

Motor

| | | |
|--------------------------|---------------------------------|----------|
| Motor Type | Baldor TEFC Induction Motor | |
| Horsepower | 3HP | 5HP |
| Speed | 3600 RPM | 3600 RPM |
| Efficiency | 76% | 88.5% |
| Power Factor | 87 | 91 |
| Power Transfer Mechanism | Poly V-belt and pulleys | |
| Bearing type | Permanently sealed ball bearing | |

Jointer Capacity and Performance

| | |
|------------------------------------|------|
| Maximum Stock Width | 12" |
| Maximum Depth of Cut for Jointing | 1/8" |
| Maximum Depth of Cut for Rabbeting | 3/4" |
| Minimum Stock Thickness | 1/2" |
| Minimum Stock Length | 12" |

Fence

| | |
|----------------------------|-------------------------------------|
| Dimensions | 47-1/2" (L) x 6" (H) |
| Fence Stops | 45 and 90 Degrees |
| Auxiliary Fence Dimensions | 47-1/2" (L) x 1-1/8" (W) x 1/2" (H) |
| Material | Extruded aluminum |

Cutterhead

| | |
|---------------------------------------|---|
| Cutterhead Type | Helical |
| Cutterhead Diameter | 3-55/64" |
| Cutterhead Speed | 5500 RPM |
| Number of Cutter Inserts | 56 |
| Number of Rows of Cutter Inserts | 4 |
| Cutter Insert Type | Four-sided, indexable German-made carbide |
| Cutter Insert Diameters | 15mm x 15mm x 2.5mm |
| Cutter Blade Angle | 30 degree |
| Cutter Insert Screw Tensioning Torque | 52-60 lbs.-inch |

Table

| | |
|--------------------------------------|----------------------------|
| Table Dimensions | 88-1/2" (L) x 12" (W) |
| Table Height Above Ground | 34-3/8" |
| Table Lifting / Adjustment Mechanism | Parallelogram |
| Material | Precision ground cast iron |

Measurements

| | |
|----------------------------|-------------------------------------|
| Measurement Units | Inch/mm |
| Measurement Devices | Wixey Digital Readout |
| Digital Readout Resolution | 1/32" / 0.005" / 0.05mm |
| Digital Readout Accuracy | ±1/500" / 0.002" / 0.05mm |
| Backup Measurement Device | Cutting depth scale with a pointer. |



Safety



| | | |
|----------------------------|-------------|-------------|
| Stock Number | 4265.101.4S | 4265.102.4S |
| Number of Dust Ports | 1 | |
| Dust Port Size | 6" | |
| Minimum CFM Required | 700 CFM | |
| Sound Rating @ 2' distance | 90-95 dB | 92-96 dB |

Others


| | |
|------------------------|--|
| Serial Number Location | On the back of the machine. |
| Spare Parts Included | Ten cutter inserts and compatible Torx screws. |
| Certification | CSA 175370 |
| Country of Origin | Taiwan |

Identification





Control Panel






Key-Operated Main Switch

On/Off Switch

Digital Readout

Safety

Oliver Machinery has made every attempt to provide a safe, reliable, easy-to-use piece of machinery. Safety, however, is ultimately depending on the individual machine operator. **Before operating this machine, please become familiar with the following safety labels and guidelines.**

| | |
|--|--|
|  DANGER | This indicates an imminently hazardous situation which, if not avoided, WILL cause death or serious injury. |
|  WARNING | This means if the warning is not taken seriously, it CAN cause death or serious injury. |
|  CAUTION | This means if the precaution is not taken, it MAY cause minor or moderate injury. |
| IMPORTANT | This is a tip for properly operating the machine to avoid machine damage. |

General Safety Guidelines

1. **FAMILIARIZE** yourself with all safety instructions found in this manual. Know the limitations and hazards associated with this machine. Do not operate/service this machine until you are properly trained.
2. **ELECTRICAL GROUNDING**, when done properly, reduce the risk of electrocution, shocks, and fire. Make certain that the machine frame is electrically grounded and that a ground lead is included in the incoming electrical service. In cases where a cord and a plug are used, make certain that the grounding plug connects to a suitable ground. Follow the grounding procedure indicated in the electrical code of your area.
3. **DISCONNECT** the machine from power before performing any service, maintenance, or adjustments. A machine under repair should be RED TAGGED to show it should not be used until the repair is complete.
4. **EYE PROTECTION**: Always wear an approved safety face shield, goggles, or glasses that complies with ANSI Z87.1 and CSA Z94.3 standards. Common eyeglasses are not safety glasses, and may not provide adequate protection.
5. **EAR PROTECTION**: Use hearing protective devices where the noise exceeds the level of exposure allowed in Section 1910.95 of the OSHA Regulations. When in doubt, use it.
6. **OTHER PERSONAL PROTECTION**: Before the operation, remove tie, rings, watch, and other jewelry. Roll up sleeves above elbows. Remove all loose outer clothing and confine long hair. Protective footwear should be used. Do not wear gloves unless it is instructed to perform a particular step(s) in the manual.
7. **GUARDS**: Keep machine guards in place for all applicable operations. If any guards are removed for maintenance, DO NOT OPERATE the machine until all guards are reinstalled. Check clearance between the guards and the cutter before starting the machine.
8. **WORKPLACE SAFETY**: Keep the floor around the machine clean. Scrap material, sawdust, oil, and other liquids increase the risk of tripping or slipping. Be sure to clean up the table before starting the machine. Make certain the work area is well lighted and that a proper exhaust system is used to

minimize dust. Use anti-skid floor strips on the floor area where the operator normally stands and mark off the machine work area. Provide adequate workspace around the machine.

9. **ACCESS CONTROL** should be enforced so only trained personnel can access the work area and operate the machine. Use a childproof power switch when applicable.
10. **STAY ALERT** at all times. Do not operate this machine while under the influence of drugs/alcohol, or when not feeling well.
11. **NEVER STAND ON MACHINE.** This prevents injuries from tipping related accidents and accidental contacts with cutters.
12. **REPLACEMENT PARTS:** Use only genuine Oliver Machinery replacement parts and accessories recommended for this machine. Generic parts made by other manufacturers may create a safety hazard and WILL void the factory warranty and other guarantees.
13. **PROPER USE:** Do not use this machine for anything other than its intended use. If used for other purposes, Oliver Machinery disclaims any real or implied warranty and holds itself harmless for any injury or damage which may result from that use.

Safety Guidelines Specific to Jointer

Before Work Begins:

1. **USE ONLY NATURAL, SOLID WOOD.** Do not joint any material such as plywood, MDF, OSB, laminate, or anything that can disintegrate during operation. Do not joint treated lumber or anything that contains harmful chemicals, as this will spread wood dust that contains such harmful chemicals. Do not attempt to joint any workpiece with loose knots or with any other foreign materials.
2. **CHECK CUTTER INSERTS:** Make sure cutter inserts are sharp, clean, and free from damages. Forcing dull/damaged cutter inserts to work invites accidents and impacts finish quality. Use the recommended amount of torque to securely fasten all inserts onto the cutterhead.
3. **SERVICING CUTTER INSERTS:** Wear heavy-duty leather gloves to protect your hands when installing new cutter inserts or rotating the existing ones. Ensure the cutterhead is thoroughly clean before installing the insert. Debris between the cutter insert and the platform can create uneven pressure, causing the insert to break, and body injuries may occur.
4. **CHECK CUTTERHEAD GUARD:** Make sure the cutterhead guard is installed and is properly tensioned. The cutterhead guard should spring back and push against the fence after it is rotated away and released.
5. **CHECK OUTFEED TABLE HEIGHT AND ALIGNMENT** to avoid a workpiece getting stuck while feeding.
6. **CHECK DEPTH OF CUT SETTING.** The maximum depth of cut for each pass is 1/8".
7. **SUPPORT LONG WORKPIECE** with auxiliary stock feeding rollers/tables. This will help to avoid injuries and improve the quality of the finish.

When Jointing:

1. **DUST COLLECTION SYSTEM** is required for this jointer. Please make sure the system is on and provide enough suction before starting the jointer.
2. **KICKBACK** happens when a workpiece is ejected at high speed during operation. Kickback projectiles can cause serious injuries or even death. Sudden movements of the workpiece from kickback can also cause hands or other body parts to get pulled into the cutterhead. The operator should be cautious at all times about possible kickback.
3. **PROPER STOCK FEEDING** reduces the chance of kickback. NEVER start the machine with anything engaging the cutterhead. NEVER start feeding until the jointer has reached its full speed. Use the right amount of downward pressure and forward force for feeding.
4. **INSPECT WORKPIECE.** Ensure the workpiece is free from nails, loose knots, and other foreign material. Use a metal detector to scan for metal objects as appropriate.
5. **NEVER** join material shorter than 12", thinner than 1/2", or narrower than 2".
6. **NEVER** rabbet material with width or thickness less than 3/4", or shorter than 12".
7. **FOLLOW THE 3-INCH RULE.** Always use push blocks when jointing materials less than 3" in thickness or width. Keep your hands at least three inches away from the cutterhead at all times when the machine is running.
8. **CUPPED WORKPIECE** should be jointed with the cupped side facing down. This prevents the workpiece from rocking.
9. **PAY ATTENTION TO GRAIN DIRECTION.** Always cut WITH grain whenever possible. Jointing against or across grain, or jointing end grain increases the chance of tear-out and kickback.

After Operation

1. **STOP THE MACHINE** if the operator leaves the machine for any reason.
2. **WAIT** until the machine comes to a complete stop.
3. **CLEAN UP** and **LOCK POWER SWITCH** before departure.

Electricals



WARNING All electrical work must be done by a qualified electrician and must meet the electrical code in your area.

Minimum Circuit Size Required for Model 4265 Jointer

| <i>Stock Number</i> | Minimum Circuit Size Required |
|---------------------|--------------------------------------|
| 4265.101.4S | 20A |
| 4265.102.4S | 15A |

Please ensure the electrical circuit for this machine meets the minimum circuit size requirement. The minimum circuit size requirement applies to a dedicated circuit that provides power to one 4265 Jointer. If more machines are sharing the same circuit, consult a qualified electrician to ensure the designated circuit is properly sized for safe operation.

If a circuit is available, but not meeting the minimum circuit size requirement listed above, a new circuit must be installed for this machine.

Grounding



WARNING Improper grounding can cause electric shock, fire, and equipment damage.

Proper grounding reduces the risk to the operator in the event of electrical malfunction or breakdown. This machine must be connected to the grounding conductor when available, and all grounding connections must meet or exceed the electrical code requirements in your area. Furthermore, all grounds must be verified and must meet or exceed the electrical requirement of the machine. If grounding is not available, consider the use of a GFCI protection device as an alternative, if this complies with the electric code in your area.

Electrical Wiring

This machine is not pre-wired with a cord and a plug. If you plan to connect the machine directly to the electrical panel (“Hardwiring”). Please ensure there is a readily accessible electrical disconnect near the machine. Refer to the section “Wiring Diagram” for wiring your machine to a power source.


If you choose to connect this machine with a plug and a cord, please use a UL/CSA listed plug. If you need an extension cord to connect to the power outlet, select a durable cord type with a high-temperature rating (90C° or above). Both plug and power cord must be sized to meet the amperage requirement of your machine.




Minimum cord size (AWG) required based on amperage draw and length of the cord:

| <i>Amps</i> | Power Cord Length | | | | |
|-------------|--------------------------|---------|---------|----------|------------|
| | 25 feet | 50 feet | 75 feet | 100 feet | > 100 feet |
| < 5 | 16 | 14 | 14 | 14 | NR |
| 5 to 8 | 14 | 14 | 14 | 12 | |
| 8 to 12 | 14 | 14 | 12 | 10 | |
| 12 to 15 | 12 | 12 | 10 | 10 | |
| 15 to 20 | 10 | 10 | 10 | NR | |
| 21 to 30 | 10 | NR | NR | NR | |

*NR: Not Recommended

| | |
|---|--|
|  WARNING | <p>Use properly sized wires that meet or exceed the power requirement of your machine. Using undersized wires may cause overheating and increase the risk of fire and machine damage.</p> |
|---|--|


| | |
|---|---|
|  WARNING | <p>Improper copper-aluminum wire connection is a fire hazard. If the power circuit available uses aluminum wires, use certified CU/AL wire connectors.</p> |
|---|---|

Setup

Shop Preparation

Space Requirement

The dimensions of this machine are 88-1/2" (L) x 38" (W). You will need additional spaces for manipulating your workpiece, electrical connection, and dust collection.



Load Limits

This machine has a shipping weight of 1057 lbs., and a net weight of 891 lbs. Please ensure all lifting tools and building structures have adequate load capacity, for transporting and supporting the total weight of this machine, the operator, and related items.

Electricals

Ensure a properly sized circuit and an electrical terminal are available nearby the machine. If the machine is to be hardwired, there must be a readily accessible power disconnect nearby, so that the machine can be disconnected from the power source for servicing and adjustments. If the machine is to be connected with a cord and a plug, please ensure a matching outlet is installed nearby the machine.

Please refer to section “Electricals” in this manual for details regarding electrical requirements.

Lighting

Adequate lighting is needed for operating this machine. Overhead, non-glare lighting should be installed.

Safety Labels

If this machine introduces a new safety hazard to your workplace, display proper warning signs in a highly visible location(s).

Dust Collection

Wood dust created by this jointer is a health hazard. Connect a dust collection system to this machine. Check air suction regularly to ensure the pipes are not jammed.

Dust masks should be available for using the jointer.



Use a dust collection system that is rated above 700 CFM. Doing so improves air quality in the workplace, and prevents the machine from jamming.

Piping of the dust collection system introduces additional air resistance and decreases the effective CFM measured at the dust ports. Ensure there is significant suction at the dust port, so dust and debris can be effectively removed from the machine.

Receiving

Your shipment should come with one wood crate. Upon receiving your shipment, check for any significant damages before signing the delivery confirmation.

IMPORTANT

If items are damaged, please call us immediately at **1-800-559-5065**

Moving Machine into the Shop

Your machine will be delivered by freight service, and it will be left outside of your workshop by default. On the day of delivery, please be sure help is available to move the machine to its final location.



4265 Jointer has a gross weight of 1057 lbs. and a net weight of 891 lbs.

Safe moving techniques and proper lifting equipment are required, or serious personal injury may occur.



Your shipment may be secured by the straps. Do not lift your shipment by the strap. They are not designed to hold the total weight of your shipment. They may snap without warning and cause serious injury and machine damage.

Always wear safety goggles and gloves when removing straps, as they may spring back violently when released and cause injury.


Unboxing

Upon removing the crate cover, you should find a jointer that is mostly assembled, and two paper boxes that contain all loose parts and accessories. Everything is covered by a plastic bag.



Inventory

Carefully unwrap the packaging and make sure all components are included in the shipment. Lay out all items received and inventory them.



| Item | Description | Quantity |
|-------------|--------------------------------------|-----------------|
| 1 | T-Handle torx drivers (T-25) | 2 |
| 2 | Spare Cutter Inserts and Torx Screws | 10 each |
| 3 | 12/14 mm Combination Wrench | 1 |
| 4 | Metric hex wrench set (5,6,8 mm) | 1 each |
| 5 | Push blocks | 2 |
| 6 | Cutterhead guard | 1 |

NOTICE: If you cannot find an item in the list above, please check if it is still attached to the packaging or inside the cabinet. Occasionally the item may have been pre-installed in the factory. See section “**Parts List**” to check if a component is included or installed.


NOTICE: This machine comes with various standard sized, non-proprietary parts. If any of these parts are missing, we are happy to deliver them to you. To have the machine up and running as soon as possible, you can also find these parts at your local hardware store.

Additional Items Recommended for Machine Setup

| Item | Purpose |
|---|--|
| Safety Glasses | Protection |
| Disposable Gloves | Protection |
| Paper Towel / Rags | Cleaning |
| Rust Inhibitor | Cast iron rust protection. |
| Straight edge | Check alignments. |
| Metric Combination Wrench Set | Assembly and Maintenance |
| Metric Hex Wrench Set | Assembly and Maintenance |
| Torque Wrench | Cutter inserts installation and for checking Torx screw tension (52-60 lbs.-inch). |
| T25 Star Bit Socket | Cutter inserts installation. |
| Ring Terminal Connector and Crimping Tool | Connecting machine to power. IMPORTANT: Always follow local electrical code for electrical work. |

Removing Machine from Crate

When all items are ready for machine setup, attach the lifting sling to the lifting hooks located at the two corners of the cabinet. Gently lift the machine from the pallet and move it to its final location.



WARNING

4265 Jointer has a net weight of 891 lbs. All lifting devices must be capable to handle the load, or serious personal injury and machine damage may occur.

Cleaning

To prevent rusting, the cast iron jointer tables are covered with machine oil and plastic film. Remove the plastic film, then wipe off the machine oil with paper towels or rags.

Once all the machine oil is removed, routinely coat the unpainted cast iron surface with rust preventive such as Boeshield® T-9 or paste wax. Do not use rust preventives that contain silicone, which is known to interfere with certain finishes and glues.



Assembly



This jointer is mostly assembled in the factory. There are a few more steps to complete before the machine is ready for a test run:

1. Setup control panel.
2. Install battery for digital readout.
3. Inspect / Adjust Jointer Tables (optional).
4. Install cutterhead guard.
5. Connect jointer to a dust collection system.
6. Connect jointer to a power source.


The approximate time for cleaning and assembly is approximately 60 minutes.

Setup Control Panel


1. To prevent damages, the control panel is lowered when it is shipped from the factory. Please follow the instructions to set up the control panel:
3. Raise the control panel to its operational position, then remount it back to the cabinet.



2. Remove all six cap screws from the control panel post.




4. Attach the last two cap screws through the table adjustment handwheel bracket.



Install Batteries for Digital Readout

Locate the digital readout on the control panel. Remove the battery cover and install 2 AA sized batteries.




Inspect / Adjust Joints Tables (Optional)


Refer to section “Maintenance -> Inspect / Adjust Joints Tables”

Install Cutterhead Guard

1. Insert cutterhead guard shaft into the hole on the rabbeting table.




2. The guard must be installed as low as possible without scratching the table.



3. There is a spring-loaded knob at the bottom of the rabbeting table. It has a cap screw that grabs the cutterhead guard shaft and keeps the guard pushing against the fence.

Rotate the knob anticlockwise until you can feel the tension from the spring, then rotate it for another 1/3 turn. Hold the knob in position and tighten the cap screw.



NOTICE: There are four screw holes on the knob. If the cap screw gets in the way while the knob rotates, relocate the screw so the cutterhead guard can rotate freely.




WARNING

Always operate this jointer with a cutterhead guard, except for some rabbeting operations. Serious personal injury may occur when operating a jointer without a cutterhead guard.

Leveling Machine

This jointer should be positioned on a level, stable floor. If the machine is rocking on the floor, or if it vibrates excessively during operation, please adjust the rubber feet to level the machine:


1. Loosen the jam nut to unlock the leveling foot.
2. Rotating the leveling foot to adjust its height.
3. Make adjustments on all other leveling feet until the machine is completely leveled.
4. Tighten jam nuts of all adjusted leveling feet.



Dust Collection

This jointer can generate a lot of wood shavings and dust. Connect a dust collection system to this machine.

The minimum CFM requirement for this jointer is 700 CFM at the dust port, which means your dust collection system should have a rating greater than 700 CFM, as air friction and leakage reduce effective CFM at the dust port.



IMPORTANT

Running this jointer without a dust collection system, or using a dust collection system with inadequate suction, will cause dust and shavings to accumulate inside the jointer. This can damage the machine and cause other hazardous situations. Check your dust collection system regularly to make sure it is not jammed or filled up.

Wiring and Grounding



Deenergize the electrical circuit before touching any enclosed, electrified parts. Touching an electrified part WILL result in serious personal injury or death.




All electrical work must be done by a qualified electrician and must meet the electrical code in your area.


Make sure the voltage of your power circuit matches the power requirement of this machine, and the circuit is sized to supply power to the jointer.

Wiring Instructions


1. **Power off before connecting any wires!!**
2. Remove the screw that secures the junction box cover.



3. The wire connector inside the junction box accepts hot conductors with ring/spade terminals. The ground conductor can be connected with a wire nut.



4. Insert the power cord through the strain relief. The strain relief can be temporarily removed from the junction box to make this task easier.



5. The picture below shows an example of how a single-phase 230V model can be connected to a power source with the ring terminals and a wire nut.

Please refer to the section “Wiring Diagram” for connecting a specific model to a power source.



IMPORTANT: Always refer to local electrical code for properly connecting any machinery to a power source.

6. Hand tighten the sealing nut of the strain relief to keep the cord in place.
7. Re-install junction box cover.

Controls and Components

Control Panel



Key-Operated Main Switch

This switch enables access control to the jointer. To restrict access, lock the switch at the “OFF” position, and the power will be cut off.

Stop Button with Emergency Reset

This stop button is equipped with an emergency shutoff feature. When it is pressed, the machine will stop, and the stop button will need to be reset before the machine can start again. To reset, simply rotate the serrated-edge rim. The button will pop up when it is reset.



Start Button

When this machine is unlocked and the emergency stop button is reset, press START will start the machine.

Infeed Table Height Adjustment Handwheel and Depth Scale

The infeed table height adjustment handwheel is located right below the control panel:

- Turn **CLOCKWISE** to raise the table.
- Turn **COUNTERCLOCKWISE** to lower the table.



The depth of cut scale next to the handwheel indicates the position of the infeed table.




Infeed Table Depth Stop Knob

As a safety feature, a depth stop is set up to prevent the depth of cut goes beyond 1/8" for jointing operations. To get more than 1/8" depth of cut for rabbeting operations, pull and hold the knob when lowering the infeed table.




Outfeed Table Height Lever and Lock


The outfeed table height adjustment lever is located below the outfeed table. The outfeed table height is locked by a locking cap screw.




The fence can be retracted and raised above the table to provide additional clearance for servicing the cutterhead.



This fence comes with an auxiliary fence for jointing thin stock. When not in use, it can be securely hung on top of the main fence with the fence hanging notch.




IMPORTANT: When deploying the auxiliary fence, please be sure the plastic supporting plates are sitting between the auxiliary fence and the table. Without these plates, the cutterhead will strike the auxiliary fence.



Fence

This extruded aluminum fence has two adjustable positive stops at 45° and 90°.



Digital Readout (DRO)

This jointer is equipped with a Wixey DRO with 0.005"/0.05mm resolution.



On/Off Button

To turn on/off this DRO. It is also for calibration in ABS (absolute) mode.

MM/IN Button

Toggles between measurement unit inch and mm. When the reading gets close to a multiple of 1/32, its fractional value will show on the screen.

ABS/INC Button

Toggles between **Absolute** and **Incremental** mode.

The absolute mode shows the total depth of cut. Once calibrated, the setting will be memorized unless the battery is exhausted, OR if a user recalibrates the DRO.

The incremental mode shows the distance the infeed table traveled since the last reset. The readings can be reset by leaving the incremental mode.


DRO Calibration

1. **Disconnect jointer from power source!!**
2. Set infeed table depth of cut to zero.
3. Turn on DRO and switch to ABS mode.
4. Hold the ON/OFF button for 3-5 seconds until "ABS" is blinking on display. As the button is released, readings will be reset to zero.
5. Press the ON/OFF button again to leave calibration mode.

Test Run

Each jointer has been inspected and calibrated before leaving the factory to meet our quality and precision standards. Due to various reasons, this jointer may need to be re-adjusted when it arrives at your workshop. It is recommended to complete this test run before using the jointer for production work, and repeat if the jointer is relocated.

Complete these quick tests to verify components are functional.

1. Remove all tools and debris from the machine. Ensure the machine is disconnected from the power source.
 2. Move and lock the fence all the way back to expose the entire jointer table. Ensure the cutterhead guard is pushing against the fence. Rotate the guard to expose the entire cutterhead, then release the guard. The cutterhead guard should rotate back to its original position.
- 
- WARNING: If the cutterhead guard needs adjustment, STOP HERE. Adjust the guard before resuming the test run.**
3. Use the provided key to turn the main switch to the OFF position, and press the emergency STOP button.
 4. Connect the machine to the power source.
 5. Press the START button. The machine should not turn on.
 6. Turn the main switch to ON, and press the START button. The machine should not turn on.
 7. Reset the emergency STOP switch by rotating it clockwise. The button should pop up. Press the START button, and the machine should turn on. The machine should be running with no excessive noise and vibration.
 8. Disconnect the machine from the power source while it is running, then reconnect the machine to power. The machine should **NOT** restart.
 9. Turn on DRO. Rotate the infeed table adjustment handwheel to raise/lower the infeed table. DRO's readings should reflect movements of the table, and the table should stop at 1/8" when is lowered without disengaging the depth stop.
 10. Set infeed table depth of cut to 1/32".
 11. Turn on the dust collection system, and surface plane a test workpiece. The workpiece should move through the jointer with ease.
 12. Inspect the workpiece for unusual tear outs and other defects.

Congratulations. You have completed the test run! Now your jointer is ready for production work. If you discover any issues from the tests, please refer to the troubleshooting section and maintenance section to diagnose issues and make adjustments.

Operation

Preparation

For safety and to achieve the best results, please take the following steps before processing any workpiece on this jointer.

Only Use Natural, Good Quality Wood

Only use this jointer for natural, quality wood materials. Cracked stock, board with loose knots, plywood, and other engineered wood products can break apart and cause severe kickbacks, which can lead to severe injuries and machine damages.

Do not use this jointer to cut treated lumber or anything that contains harmful chemicals. This will spread wood dust that contains such harmful chemicals.

Inspection

Carefully inspect workpieces for foreign objects. Nails, staples, rock chips, and other objects embedded on the wood surface will damage the jointer. It is advised to clean a workpiece with a stiff brush to remove all dirt and foreign objects ahead of time, especially for rough sawn or reclaimed lumber. Use a metal detector to scan for metal objects as needed.

Check Dimensions

For safety, NEVER process stock that is:

1. Shorter than 12"
2. Thinner than 1/2", or
3. Less than 2" wide (for surface planing).

Support Long Workpiece

Support long stock with rollers or other devices to avoid injuries. This also helps in creating a smooth, consistent finish.

Check Moisture Content

Check the moisture content of workpieces. "Green wood" with moisture content over 20% will not cut properly and may jam the machine. Excessive moisture content will also cause the jointer's unpainted surface to rust. Besides, as the workpiece dries, the once-flattened surface can become fuzzy and warped again. It is recommended to allow a workpiece to dry and stabilize before it is processed.

Warped Stock


Avoid using boards with severe warping, as they can be unstable and might cause severe kickbacks during operation.

Glue Deposits

Glue left on the workpiece surface can dull cutters and lower cut quality. Scrape off all glue deposits from the workpiece before jointing a workpiece.

Inspect Wood Grain

This jointer is designed to cut WITH the grain. Avoid cutting against/across/end grain as severe kickback and chipping may occur.




Sometimes it is impossible to cut with the grain for the entire length of a workpiece. In this case, try feeding the workpiece in opposite direction and see what works best. Reducing the depth of cut and feed rate can also help improving cut quality.

Squaring Stock

Jointer is commonly used in conjunction with the planer and table saw for squaring stock. Rough, warped stock is milled so it becomes flat and parallel along both length and width, and with the length and width perpendicular to one another.

It takes four steps for squaring stock:

1. Surface Planing - The bottom face of the stock is flattened by a jointer. The concaved face should be chosen for this step.
2. Thickness Planing - The top face of the stock is flattened by a thickness planer. In this step, the workpiece can be planed down to the desired thickness.
3. Edge Jointing - The concaved edge is straightened and squared on a jointer.
4. The last edge is straightened with a rip cut on a table saw, with the jointed edge placed against the table saw fence. In this step, the workpiece can be cut to the desired width.



Serious injury or death can result from machine kickback or accidental contact to the cutterhead. Follow these safety rules to reduce your risks for all jointing operations:



WARNING

- Begin operation with the concave, or the most stable surface for jointing.
- Feed stock with steady, controllable force. Remain stable stance and balance.
- Use eye and ear protection devices.
- Cutterhead guard must be installed for all jointing operations.
- Keep hands at least 3" away from the cutterhead.
- Use push blocks whenever possible.




CAUTION


Ensure the dust collection system is functional and use a dust mask to avoid inhaling harmful airborne particles.

Surface Planing


1. **Inspect stock for quality issues and grain orientation before the operation.**
2. Begin surface planing with the concave face when present (see examples on the right).
3. Adjust the depth of cut of the infeed table. Do not remove more than 1/16" per pass to allow better control over the workpiece.
4. Set fence to 90°.
5. Start the jointer and dust collection system.




6. To initiate a cut, stand near the infeed table, slightly behind the cutterhead. Use the left hand to push firmly on stock against the fence and infeed table, and use the right hand to feed the stock from the back. Use push blocks whenever permissible.




7. Feed a small section of stock across the cutterhead with pressure against the fence and the infeed table.



8. As the left hand approaches the cutterhead, lift it up and move it across the cutterhead to avoid accidental contact. Put the left hand on the stock that sits on the outfeed table, and continue to feed. Maintain control of stock with the right hand while repositioning the left hand.



9. As the right hand approaches the cutterhead, reposition the right hand as shown in the diagram. The operator should move forward and continue feeding next to the outfeed table. Maintain control of stock with the left hand while repositioning the right hand.



10. From this point on, continue feeding only on the outfeed table until the entire length of stock has moved across the cutterhead. Maintain feed rate to produce a smooth cut with no burnt marks.

NOTICE: Putting downward pressure on the infeed table is unnecessary in this stage, and may cause the stock to bow, taper, or snipe at the end.

11. Repeat steps 6-10 until the entire surface is cut flat.


TIP: For new jointer users, practice stock feeding with the depth of cut set to 0". This helps to perfect the skills before actual operations.

TIP: To ensure the entire surface is cut, some woodworkers leave pencil marks on the entire length of stock before the final passes, then verify all marks are removed after a pass.

TIP: For thin stock, avoid excessive downward pressure which will flatten any cup or warp as the stock pass through the cutterhead. After pressure is released, the cup or warp will spring back. Only apply adequate pressure to maintain control of the stock when feeding.

Edge Jointing

1. **Inspect stock for quality issues and grain orientation before the operation.**
2. Begin edge jointing with the concave edge when present.



3. Set the depth of the cut to the minimum amount to obtain a straight edge. Do not set cuts deeper than 1/8" in a single pass.
4. Set fence to 90°.
5. Start the jointer and the dust collection system.
6. Hold the best-flattened face of the workpiece firmly against the fence throughout the entire cut. Use push blocks whenever permissible.



7. Follow steps [6-10] in "Surface Planing" for feeding stock through the jointer. Repeat the process until the entire edge is jointed flat and square.

Beveling

Instructions and precautions for edge jointing apply to beveling except:

- Instead of setting the fence to 90°, set the fence tilt to the desired angle of cut using a protractor.
- Reduce the depth of cut to **1/16"-1/8"** based on the width of the bevel and hardness of the workpiece.

Rabbet Cutting

A rabbet is a groove cut along the edge of a workpiece. This jointer is capable of making rabbet cuts as deep as 3/4", and with a width as little as 5/16". Depends on the requirements and constraints of your project, a jointer, or other tools such as a table saw, router, or other hand tools, can be the best tool for your rabbeting needs. Always consider safety when choosing a tool for rabbeting.

Performing a rabbeting cut with this jointer may require the cutterhead guard removed. Promptly re-install the guard after the rabbeting operation completes.

1. **Inspect stock for quality issues before the operation. The surfaces for rabbeting must be flat and squared.**
2. Set fence to 90°
3. Slide fence forward to set the width of cut. The amount of exposed cutterhead is the width of the rabbet. With the main fence, the minimum width of cut is 1-7/16". Using the auxiliary fence can further reduce the width of cut to 5/16".
4. Remove the cutterhead guard as needed.
5. Lower the infeed table to the desired depth of cut for each pass. Disengage the infeed table depth stop as the infeed table travels below 1/8". Maximum depth of cut for rabbeting is 3/4".
CAUTION: For safety, never exceed 1/8" per pass.
6. Start the jointer and dust collection system.
7. Place workpiece firmly against the fence and infeed-rabbeting table. Use push blocks whenever permissible.
8. Follow steps [6-10] in "Surface Planing" for feeding stock through the jointer. Repeat the process until reaching the desired depth of the rabbet cut.



8. Follow steps [6-10] in "Surface Planing" for feeding stock through the jointer. Repeat the process until reaching the desired depth of the rabbet cut.

CAUTION: Beware that the rabbeting table is short and narrow. Take extra caution and support of the entire workpiece throughout the operation.



If the cutterhead guard is removed for rabbeting operation, use extreme caution when performing cuts. Reinstall the guard immediately when the operation completes.

Common Cutting Problems

Snipe

Occurs when too much pressure is applied as a workpiece enters or leaves the cutterhead. This can also cause by improper table settings.

To mitigate this problem, apply even feeding pressure throughout the entire workpiece. Once the workpiece is past the cutterhead, downward pressure should be focused on the outfeed table only. Ensure the outfeed table is not positioned way below the cutter head.



Chipping

Happens when cutting against the grain direction. For highly figured lumber, and areas near a knot, some amount of chipping is normal. In this case, moistening the problematic area before jointing can sometimes mitigate the issue.

Chipping can also cause by dirty or dull cutters. If chipping happens while jointing straight grain stocks, inspect cutter inserts and remove all resin buildups. Rotate/replace dull cutter inserts when they are dull.



Fuzzy Grain

Can happen when planing wood with high moisture content or if the cutter is dull. Sometimes fuzzy grain is unavoidable due to the nature of certain wood types. To mitigate this issue, avoid using wood with high moisture content and use sharp cutters.

Accessories

Oliver Machinery has a collection of accessories and add-ons to enhance the productivity of your jointer. Please visit our website OLIVERMACHINERY.NET to purchase these items.

You may also call **1-800-559-5065** or email PARTS@OLIVERMACHINERY.NET to purchase these items. We are available Monday through Friday, 9 AM - 5 PM Pacific Time.

460V Conversion Kit



This 460V Conversion kit allows you to convert a three-phase model (**4265.102.4S**) that is pre-wired to 230V to operate on 460V. Installation of this kit should be done by a qualified electrician. You may also order the 460V three-phase model directly from Oliver Machinery. We can pre-install this kit for you.

Parts number:

491192-000 440V Magnetic Contactor

491191-000 440V Overload RA-20

Cutter Inserts



Genuine four-sided indexable carbide cutter insert that will fit the cutterhead of Oliver **4265 Jointer**. Made in Germany.

Parts number: **P-15mm 4S**

Touchup Paint



Keeping all painted surfaces in good condition keeps your machine looks nice and prevents rusting. We have pre-mixed spray paint available in Oliver-Blue for purchase.



WARNING

Using unapproved accessories may cause this machine to malfunction, resulting in serious injury and/or machine damage. Only use accessories recommended for this machine.

Power Feeder

Two models of power feeders are available for the 4265 Jointer. They can be installed on the power feeder mount located behind the outfeed table.



Features

- Polyurethane covered rollers provide excellent grip while protecting the work surface.
- Eight feed speeds and choice of three or four rollers to fit any application.
- Versatile stand allows adjustment of 10" in height and 18" in reach.
- Powerful TEFC motor is available in single or three-phase.
- CSA Listed



| Model | APF0038 |
|-------------------|--|
| Stock Number | APF0038.001 1HP, 1Ph, 230V (4.2A) |
| Stock Number | APF0038.002 1HP, 3Ph, 230V (3.4A) |
| Number of Rollers | 3 |
| Roller Size | 4-3/4"(D) x 2-3/8"(W) |
| Feed Speed | 8 Speeds: 6.5 / 13 / 18 / 22 / 36 / 43 / 55 / 108 FPM |
| Net Weight | 137 lbs. |




| Model | APF0048 |
|-------------------|--|
| Stock Number | APF0048.001 1HP, 1Ph, 230V (4.2A) |
| Stock Number | APF0048.002 1HP, 3Ph, 230V (3.4A) |
| Number of Rollers | 4 |
| Roller Size | 4-3/4"(D) x 2-3/8"(W) |
| Feed Speed | 8 Speeds: 6.6 / 13 / 18 / 22 / 36 / 43 / 55 / 108 FPM |
| Net Weight | 146 lbs. |

Please visit our website at WWW.OLIVERMACHINERY.NET/ACCESSORIES for other recommended accessories.

Maintenance

Routine maintenance keeps your jointer in top shape. Please follow the maintenance schedule below, and use the maintenance record worksheet attached in the back of the manual to document all tasks completed. **NOTICE:** Maintenance schedule may vary for individual users due to different situations and safety requirements.

| | |
|---|---|
|  WARNING | Disconnect the machine from the power source before any maintenance work is performed. After servicing the jointer, remove all wrenches and tools before restarting the machine. Failure to comply can cause serious injury! |
|---|---|

Maintenance Schedule

| Interval | Task |
|----------------|--|
| Every day | Remove dust buildups from the jointer and dust collection system. |
| | Inspect the power cord for signs of aging and damages. Replace as needed. |
| Every week | Inspect and clean the cutterhead. Remove any dust and resin accumulation. |
| | Inspect/rotate/replace worn cutter inserts. |
| | Apply rust protectant on unpainted cast iron surfaces. |
| | Verify infeed/outfeed tables are coplanar. |
| Every month | Check V-belt tension and replace if the belt shows signs of cracking or glazing. |
| Every 6 months | Lubricate worm gears with grease. |

Notice: Motor bearings are permanently sealed and lubricated, and do not require lubrication.

Inspect / Adjust Jointer Tables


Each jointer has been inspected and calibrated in the factory and should not require adjustments initially. When a jointer consistently makes problematic cuts, perform these checks, and make adjustments as needed.

Inspect Outfeed Table Height

1. **Disconnect jointer from power source!!**
2. Put on leather gloves.



3. Remove cutterhead guard.
4. Move fence assembly all the way back to expose the entire table.
5. Place a straight edge over the centerline of the outfeed table so it hangs over the cutterhead.




6. When the outfeed table height is properly set, cutters should be barely scraping the straight edge when the cutterhead rotates. Follow the next section to make adjustments as needed.

If the outfeed table height is set properly, jump to section “**Inspect Outfeed Table Parallelism**”.


Adjust Outfeed Table Height

1. **Disconnect jointer from power source!!**
2. Loosen the cap screw that locks the outfeed table.



3. Adjust outfeed table height with the lever. With a straight edge sitting on the outfeed table, cutters should be barely touching the straight edge when the cutterhead rotates.
4. Below the base of the lever, there are two stop bolts for setting the maximum and minimum height of the outfeed table.

If these stop bolts need to be adjusted, loosen the jam nuts, and retighten them when adjustments complete.




5. When the height of the outfeed table is adjusted, tighten the locking cap screw to lock its height.

Inspect Outfeed Table Parallelism

1. **Disconnect jointer from power source!!**
2. Place a straight edge on the outfeed table in positions as shown below:



3. Make sure the straight edge is hanging above the cutterhead:




4. In each position, carefully rotate the cutterhead. When the outfeed table is in parallel with the cutterhead, cutters should be barely scraping the straight edge when the cutterhead rotates.
5. If the outfeed table and cutterhead are out of alignment, move to section "**Adjust Table Parallelism/Coplanarity**".

If the outfeed table is in parallel with the cutterhead, proceed to the next section "**Inspect Infeed Table**"

Inspect Infeed Table

1. **Disconnect jointer from power source!!**
2. **NOTICE:** Make sure the outfeed table is properly adjusted before continue.
3. Place a straight edge that splits evenly on both the infeed and the outfeed table.
4. Raise the infeed table so that it is at the same height as the outfeed table. When proper height is set, the straight edge will sit flat and flush with the infeed and the outfeed table. Rotate carbide cutter away if it contacts the straight edge.
5. Move the straight edge across the tables in positions as shown in the picture below. Rotate carbide cutter away if it gets in the way.



6. In each position, the straight edge should sit flat and fit flush with both infeed and outfeed tables.
7. If infeed/outfeed tables are out of alignment, move to section "**Adjust Table Parallelism/Coplanarity**".
8. Otherwise, congratulations! The jointer tables are well calibrated for your next project!

Adjust Table Parallelism/Coplanarity

Adjusting table parallelism and coplanarity take time, precision, and patient. The entire process can take over an hour or more. Check the amount of misalignment against tolerance before making adjustments.

| Measurement | Tolerance |
|--|----------------|
| Outfeed Table / Cutterhead Parallelism | $\leq 0.004''$ |
| Infeed / Outfeed Table Parallelism | $\leq 0.01''$ |

For best results, a long and precise straight edge is required for adjustments.


1. **Disconnect jointer from power source!!**
2. Remove the depth stop knob.




3. Remove the cutterhead cover.




4. Remove all metal four metal panels that conceal the parallelogram mechanism.







5. Each panel is secured by two cap screws, which are covered by plastic caps. Use a straight head screwdriver to remove the plastic cover, then remove the hex cap screw with a 5mm hex wrench.




6. This picture shows the jointer with the parallelogram mechanism exposed. Table parallelism /coplanarity can be adjusted by rotating the eccentric nuts on the shafts [1-4]. There is a pair of eccentric nuts located on each end of these shafts.



7. Locate and loosen the set screws for locking the eccentric nuts as shown in the pictures:



8. The eccentric nuts should be fairly loose once they are unlocked. Rotate the eccentric nuts to align the outfeed table and cutterhead.
9. **IMPORTANT:** While rotating the eccentric nuts, ensure they are pushed against the holding bracket. Leaving any gaps in between may cause the table to shift sideways.




10. Repeat the steps in “**Inspect Outfeed Table Parallelism**” to verify adjustments.
11. When adjustments complete, retighten the set screws to lock all outfeed table eccentric nuts.

12. With the fence locked, gently rock the fence to ensure the outfeed table is stable. If the outfeed table is rocking, eliminate all gaps between eccentric nuts and the bracket.
13. Adjust the infeed/outfeed table parallelism using the infeed table eccentric nuts. Repeat the steps in “**Inspect Outfeed Table Parallelism**” when making adjustments. Again, leave no gaps between the eccentric nut and the bracket.
14. Lock all eccentric nuts when adjustments complete.
15. With the infeed table realigned, it may need additional adjustments. See section “**Infeed Table Adjustments**” for details.
16. Reinstall all panels and cutterhead guard when all adjustments complete.

Infeed Table Adjustments

After a full table realignment, the infeed table height should be re-zeroed, and a few components of the infeed table will need to be adjusted.

1. **Disconnect the jointer from the power source!!**
2. To re-zero the infeed table height, raise the infeed table so it is approximately at the same height as the cutting arc of the cutterhead.
3. Place a straight edge over the infeed table so it hangs over the cutterhead.



4. Fine-tune the table height to set the depth of cut to zero. When properly set, cutters should be barely scraping the straight edge when the cutterhead rotates.
5. With the infeed table height zeroed, follow the steps in **"DRO Calibration"** to re-zero the digital readout.
6. Check if the infeed table height scale is still pointing at zero. If not, loosen the 2 hex screws and readjust the pointer.




Infeed Table Positive Stops Adjustments


Under the infeed table, there are three positive stops:

Minimum Depth Stop - When properly adjusted, it should stop the infeed table when the depth of cut is between 0"-1/32".

Maximum Depth Stop - Prevents the infeed table from lowering too much and getting more than 3/4" depth of cut.



Depth Stop for Jointing – Limits the depth of cut to 1/8" for jointing operations. This positive stop is located behind the depth stop knob, which is accessible when the panel is removed.



To test this depth stop, make sure the bracket as shown in the picture above aligns with the stop bolt, then lower the infeed table. If this positive stop is set correctly, it will stop the table at 1/8".

To Make Adjustments:

1. **Disconnect the jointer from the power source!!**
2. Loosen the jam nut that locks the stop bolt.
3. Rotate the stop bolt until it stops the infeed table at the correct height.
4. Re-tighten the jam nuts.


Cutterhead Maintenance

Rotate / Replace Cutter Inserts




Cutter inserts are extremely sharp. Protect your hands with thick leather gloves to avoid injuries.

1. **Disconnect jointer from power source!!**
2. Put on leather gloves.
3. Remove cutterhead guard.
4. Move fence assembly all the way back and above the table to expose the cutterhead.
5. Remove dust and resin accumulations on cutterhead and areas nearby.
6. Rotate cutter inserts 90° clockwise when they get dulled or nicked. Use a permanent marker to mark the new edge to be used.
7. To rotate/replace a cutter insert, remove the Torx screw with a T-25 Torx bit. Turn **COUNTERCLOCKWISE** to loosen the screw.
9. Reinstall cutter insert with the marked cutting edge facing out.
10. Inspect the Torx screw. Replace any damaged screws. Lubricate screw thread with a thin coat of lightweight machine oil.
IMPORTANT: Do not use an excessive amount of lubrication, or the Torx screw and the cutter insert will not sit properly.
11. Using a torque wrench, re-tighten the Torx screw with 52-60 lbs.-inch of torque.
IMPORTANT: Do not overtighten the screw or the inserts may break. Do not use power tools to tighten the Torx screws as it can strip the screws.



8. With the cutter insert removed from its platform, thoroughly clean the cutter insert platform with a vacuum or compressed air.
12. Reinstall cutterhead guard and remove all tools from the table when servicing is done.




IMPORTANT: Obstacles between the insert and cutterhead platform will create uneven pressure against the insert. This will lower cut quality and may cause the insert to crack.

Adjust Fence Positive Stops

The fence assembly has two positive stops at 90° and 45°. They were calibrated in the factory and should not require initial adjustments.

Adjust 90° Positive Stop


1. Loosen two jam nuts and positive stop set screws.



2. Use a machinist square to set the fence at 90 degrees.
3. Rotate set screws to reset the positive stop.
4. With the set screws holding in place, tighten the jam nuts.
5. Re-check fence stop settings.

Adjust 45° Positive Stop

1. Loosen the jam nut and positive stop bolt.



2. Use a protractor to set the fence at 45 degrees.
3. Rotate the stop bolt to reset the positive stop.
4. With the stop bolt holding in place, tighten the jam nut.
5. Re-check fence stop settings.


Adjust Belt Tension




CAUTION

Belt and pulleys may be hot after operations. Allow components to cool before servicing.


1. **Disconnect jointer from power source!!**
2. Remove the motor access panel and the belt cover.




3. Apply moderate pressure on the V-belt midway between the two pulleys. Properly tensioned V-belt should deflect by approximately 1/4".




4. If V-belt tension needs to be adjusted, loosen both lower motor mounting bolts (#1). Lower the motor until proper belt tension is reached. Secure the motor mounting plate by tightening both the upper mounting bolts (#2) and the lower mounting bolts.



5. If V-belts need replacement, push the belt towards the motor to walk the belt out from the motor pulley.



If the belt is too tight to remove, temporarily loosen the upper mounting bolts (#2). Raise the motor to loosen the belt, and remove it from the pulleys.




6. Install a new belt and make sure the belts sit into the grooves of pulleys.
7. Adjust belt tension and re-secure motor as needed.
8. Replace belt cover and motor access panel when maintenance completes.


Align Belt Pulleys

The belt pulleys were aligned in the factory and should not require further adjustments. Check pulley alignment if the belt is slipping off the pulleys, or if the belt wears prematurely.

1. **Disconnect jointer from power source!!**
2. Remove the motor access panel and the belt cover.



3. Use a straight edge or a tight string to check the alignment of the belt pulleys.
4. Adjustments can be made by shifting the motor pulley. Loosen the two set screws with a 5mm hex wrench, and the motor pulley can move along the motor shaft.



5. Realign the motor pulley with the cutterhead pulley.
6. Retighten the motor pulley locking screws, then close the belt cover and motor access panel when adjustments complete.

Troubleshooting

Mechanical / Electrical Issues

| Problem | Possible Cause | Possible Solution |
|---|---|--|
| Machine does not start. | Machine is not connected to a power source. | <ol style="list-style-type: none"> 1. Make sure the machine is plugged in, or the power disconnect is at the ON position. 2. Check the electrical panel for a tripped circuit breaker or a blown fuse. 3. Ensure all electrical connections have good contacts. |
| | Low voltage / current. | Have an electrician to check/repair the power circuit. |
| | Faulty switch/motor/capacitor. | Contact customer service for further assistance. |
| Machine trips thermal protection/circuit breaker, or blow fuses. | Machine is undersized for the operation. | Reduce the depth of cut and/or feed rate. |
| | Workpiece moisture level is too high. | Only joint wood with a moisture level below 20%. |
| | Machine is jammed. | Make sure the cutterhead is not jammed by woodchips. Check dust chute and clear blockages. |
| | Too much load on a circuit. | Make sure the power circuit is sized for this machine. If the circuit is shared, ensure it is sized to supply power for all items in the circuit. |
| | Motor/capacitor issue. | Contact customer service for further assistance. |
| Machine stalls during operation. | Machine is undersized for the operation. | Reduce the depth of cut. Lower feed rate. |
| | Dull cutters. | Rotate/replace cutter inserts. |
| | Belt slipping. | Clean belt and pulleys. Adjust belt tension. |
| | Motor/capacitor issue. | Contact customer service for further assistance. |
| Machine stopped during an operation. | Thermal overload protection triggered. | Hit the STOP button and wait for at least 3 minutes. When the machine is cooled down, overload protection will reset automatically. Reduce the depth of cut and feed rate before continue. |

| Problem | Possible Cause | Possible Solution |
|--|--|--|
| Outfeed table is stuck/difficult to adjust. | Outfeed table is locked. | Loosen the locking cap screw before adjusting the outfeed table. |
| Digital readout not functional. | Dead battery. | Replace battery. |
| Unable to lower infeed table below 1/8" | Depth stop is engaged. | Pull infeed table depth stop knob while lowering the infeed table. NOTICE: Only set depth of cut greater than 1/8" for rabbeting operations. |
| Outfeed table is loose and moves with the fence. | There is play in the parallelogram mechanism. | Check the parallelogram mechanism and eliminate any gaps between the eccentric nut, bracket, and shafts. Ensure all eccentric nuts are locked by the set screws, and each set screw is locked by blue Loctite. |
| Workpiece is caught on the edge of the outfeed table. | Outfeed table is set too high. | Adjust the outfeed table to ensure it is flush with the cutting arc of the cutterhead. |
| Uneven wear on cutter inserts | One section of cutterhead is used more than another. | Occasionally adjust fence's depth setting so the entire cutterhead is utilized. |
| Machine vibrates excessively or makes unexpected noise. | Damaged cutter inserts. | Replace cutter inserts. |
| | Machine stands on an uneven floor. | Reposition machine on a flat, level surface. Adjust leveling feet. |
| | V-belt worn, slipping, or hitting belt cover. | Clean belt and pulleys. Adjust belt tension. Replace V-belt if it shows signs of aging. |
| | Improper motor mounting. | Check and adjust motor mounting. |
| | Loose components. | Tighten fasteners of the component. |
| | Worn bearings. | Contact customer service for assistance. |


Operation / Quality-Related Issues

| Problem | Possible Cause | Possible Solution |
|------------------------------------|---|--|
| Workpiece came out twisted. | Improper feeding. | Use the outfeed table as the reference point for feeding. Apply even pressure and feed rate on the entire workpiece. |
| | Outfeed table is not in parallel with the cutterhead. | Ensure the outfeed table is in parallel with the cutterhead, and the outfeed/infeed tables are coplanar. |
| | More passes are needed. | Significantly twisted boards take multiple passes to flatten. |

| Problem | Possible Cause | Possible Solution |
|---|---|--|
| Excessive snipe | Outfeed table too low. | Adjust the outfeed table to ensure it is flush with the cutting arc of the cutterhead. |
| | Too much downward pressure when feeding the end of a workpiece. | Once the workpiece reaches the outfeed table, use the outfeed table as the reference. Reduce feeding pressure apply to the workpiece that is still on the infeed table. |
| Chipping | Too much material removed in one pass. | Reduce the feed rate or the depth of cut. |
| | Planing across/end grain. | Do not use a jointer to cut across/end grain. |
| | Damaged cutter. | Rotate/replace cutter insert. |
| | Cutting against grain; or knots. | Avoid processing workpieces with knots. Cut WITH grain whenever possible. When jointing a workpiece with complicated grain pattern, reduce the depth of cut. Sometimes moistening problematic areas can reduce chipping. |
| Fuzzy looking finish. | Wood moisture content too high. | Only process wood with less than 20% moisture content. |
| | Dull cutter. | Rotate/replace cutter insert. |
| | Some wood types tend to have fuzzy grain. | Adjust feed rate or the depth of cut. Use sharp cutters. |
| Glossy looking finish. | Dull cutter. | Rotate/replace cutter insert. |
| | Cutting depth too shallow. | Increase depth of cut. |
| Long line or ridges running along the length of the board. | Chipped cutter. | Rotate/replace cutter insert. |
| Finished stock has uneven front-to-back thickness. | Cutterhead is not flush with the outfeed table. | Adjust the outfeed table to ensure it is flush with the cutting arc of the cutterhead. |
| | Inconsistent feeding pressure applied to the workpiece. | Apply even feeding pressure on the workpiece. Keep feed rate consistent. |
| Finished stock is concave/convex in the middle. | Infeed/outfeed table are not coplanar. | Ensure the outfeed table is parallel with the cutterhead, and the outfeed/infeed tables are coplanar. |

Wiring Diagram

For Stock # 4265.101.4S (230V, 1Ph)



Parts List

Fence Assembly







Table and Cutterhead Assembly



Base Assembly



Motor and Cabinet



| Key | Part Number | Descriptions | Specifications | QTY |
|-----|-------------|----------------------------|-----------------|-----|
| 1 | 000104-104 | Cap Screw | M8*1.25P*16 | 2 |
| 2 | 006305-100 | Spring Washer | 8.2*13.7 | 10 |
| 3 | 174771-000 | Cover | | 1 |
| 4 | 000804-101 | Flat Head Cap Screw | M5*0.8P*8 | 10 |
| 5 | 250372-615 | Knob | | 1 |
| 6 | 361331-904 | Rod | | 1 |
| 7 | 361330-902 | Axis | | 1 |
| 8 | 011003-104 | Spring Pin | 5*25 | 1 |
| 9 | 008304-800 | Lock Nut | M6*1.0P(10B*7H) | 8 |
| 10 | 330066-000 | Bushing | | 2 |
| 11 | 330068-000 | Plate | | 1 |
| 12 | 361329-000 | Rod | | 2 |
| 13 | 000101-101 | Cap Screw | M4*0.7P*8 | 2 |
| 14 | 011002-110 | Spring Pin | 4*16 | 2 |
| 15 | 174615-904 | Position Plate | | 2 |
| 16 | 006302-300 | Spring Washer | 5.1*9.3 | 4 |
| 17 | 000102-103 | Cap Screw | M5*0.8P*10 | 14 |
| 18 | 002602-102 | Cap Lock Screw | M6*1.0P*20 | 6 |
| 19 | 006303-100 | Spring Washer | 6.5*10.5 | 9 |
| 20 | 006001-010 | Flat Washer | 5.2*12*1.5t | 2 |
| 21 | 310543-909 | Fence Linear Guide Bracket | | 1 |
| 22 | 130383-903 | Square Nut | | 1 |
| 23 | 381411-904 | Sliding Arm | | 2 |
| 24 | 008004-100 | Hex Nut | M5*0.8P(8B*4H) | 5 |
| 25 | 000202-105 | Set Screw | M5*0.8P*30 | 1 |
| 26 | 034403-001 | Linear Bearing | LM20UU | 2 |
| 27 | 000202-106 | Set Screw | M5*0.8P*20 | 1 |
| 28 | 006001-125 | Flat Washer | 15.5*25*2.5t | 3 |
| 29 | 230405-000 | Adjust Handle | | 1 |
| 30 | 361333-904 | Shaft | | 1 |
| 31 | 174620-904 | Fence Adjust Plate | | 1 |
| 32 | 000802-102 | Flat Head Cap Screw | M8*1.25P*20 | 2 |
| 33 | 000103-110 | Cap Screw | M6*1.0P*35 | 4 |
| 34 | 006004-205 | Flat Washer | 6.8*14*0.3t | 4 |
| 35 | 000103-108 | Cap Screw | M6*1.0P*25 | 2 |

| Key | Part Number | Descriptions | Specifications | QTY |
|-----|-------------|---------------------------------------|--------------------|-----|
| 36 | 006011-023 | Flat Washer | 6.3*13*2.0t | 8 |
| 37 | 300119-911 | Shaft Block | | 2 |
| 38 | 006001-044 | Flat Washer | 8.5*16*0.8t | 2 |
| 39 | 030101-001 | Ball Bearing | 608-ZZ | 1 |
| 40 | 310542-911 | Fence Position Bracket | | 1 |
| 41 | 000103-811 | Cap Screw | M6*1.0P*40 | 2 |
| 42 | 361359-902 | Stud | | 2 |
| 43 | 174622-904 | Link | | 2 |
| 44 | 000003-108 | Hex Screw | M8*1.25P*40 | 1 |
| 45 | 008006-100 | Hex Nut | M8*1.25P(13B*6.5H) | 5 |
| 46 | 174616-904 | Plate | | 1 |
| 47 | 000104-110 | Cap Screw | M8*1.25P*30 | 18 |
| 48 | 006001-009 | Flat Washer | 5.2*10*1.0t | 13 |
| 49 | 000402-104 | Pan Phillips Screw | M5*0.8P*12 | 2 |
| 50 | 361367-902 | Link Bolt | | 1 |
| 51 | 250602-621 | Plate | | 2 |
| 52 | 310522-911 | Auxiliary Fence | | 1 |
| 53 | 001102-504 | Self-Tapping Screw | M4*1.59P*12 | 4 |
| 54 | 290104-902 | Shoulder Screw | | 2 |
| 55 | 174614-904 | Supporting Plate | | 2 |
| 56 | 360249-905 | Pin | | 2 |
| 57 | 310518-911 | Fence | | 1 |
| 58 | 051396-000 | Fence Base | | 1 |
| 59 | 006001-068 | Flat Washer | 10*20*2.0t | 2 |
| 60 | 006307-100 | Spring Washer | 10.2*18.5 | 17 |
| 61 | 000105-103 | Cap Screw | M10*1.5P*30 | 7 |
| 62 | 051400-902 | Bearing Housing | | 2 |
| 63 | 000105-107 | Cap Screw | M10*1.5P*50 | 4 |
| 64 | 924682-000 | Cutterhead Assembly | | 1 |
| | 038201-101 | Torx Screw | #10-32NF*1/2" | 56 |
| | P-15mm 4S | Carbide Inserts (Sold in Packs of 10) | 15*15*2.5t | 56 |
| 65 | 012004-002 | Key | 6*6*30 | 1 |

| Key | Part Number | Descriptions | Specifications | QTY |
|------|-------------|----------------------------|--------------------------------|-----|
| 66 | 001903-105 | Set Lock Screw | M8*1.25P*8 | 4 |
| 67 | 381072-902 | Cutterhead Pulley | | 1 |
| 68 | 030209-002 | Ball Bearing | 6205-2NSE | 2 |
| 69 | 922158-000 | Cutterhead Guard Assembly | | 1 |
| 69.1 | 300023-000 | Cutterhead Guard | | 1 |
| 69.2 | 000204-105 | Set Screw | M8*1.25P*20 | 1 |
| 69.3 | 360869-901 | Guard Pivot Shaft | | 1 |
| 70 | 051183-000 | Rabbeting Table | | 1 |
| 71 | 200105-615 | Sponge | 30*30*22(L*W*H) | 1 |
| 72 | 051395-000 | Table (infeed or outfeed) | | 2 |
| 73 | 000103-102 | Cap Screw | M6*1.0P*10 | 8 |
| 74 | 174645-000 | Rear Cover (Left) | | 1 |
| 75 | 042505-000 | Plug | HP-13 | 8 |
| 76 | 300118-909 | Position Bracket | | 1 |
| 77 | 174646-000 | Rear Cover (Right) | | 1 |
| 78 | 174649-156 | Scale Pointer | | 1 |
| 79 | 361298-902 | Table Shaft | | 4 |
| 80 | 009004-100 | Hex Nut | 1/4"-20NC(11B*5.5H) | 2 |
| 81 | 230275-000 | Set Screw | 1/4"-20NC*3/4" | 2 |
| 82 | 280165-000 | Torsion Spring | | 1 |
| 83 | 380825-901 | Knob | | 1 |
| 84 | 000104-708 | Cap Screw | M8*1.25P*25 | 1 |
| 85 | 361336-902 | Round Standoff | | 1 |
| 86 | 290028-901 | Shoulder Screw | | 2 |
| 87 | 174655-902 | Position Plate | | 1 |
| 88 | 009103-100 | Lock Nut | 1/4"-20NC(11B*8H) | 1 |
| 89 | 000702-104 | Socket Flat Head Hex Screw | Only used SN 192984 and beyond | 1 |
| 90 | 280082-000 | Torsion Spring | | 1 |
| 91 | 000102-116 | Cap Screw | M5*0.8P*15 | 3 |
| 92 | 174644-000 | Front Cover (Left) | | 1 |
| 93 | 174643-000 | Front Cover (Right) | | 1 |
| 94 | 230156-615 | Knob | | 1 |
| 95 | 250496-615 | Handle | | 1 |
| 96 | 361300-902 | Rod | | 1 |
| 97 | 008011-100 | Hex Nut | M16*2.0P(24B*13H) | 1 |

| Key | Part Number | Descriptions | Specifications | QTY |
|-----|-------------|---------------------|--------------------------------|-----|
| 98 | 051401-902 | Elevation Bracket | | 1 |
| 99 | 001902-102 | Set Lock Screw | M6*1.0P*8 | 8 |
| 100 | 002602-101 | Cap Lock Screw | M6*1.0P*12 | 10 |
| 101 | 361335-902 | Shaft | | 4 |
| 102 | 381392-902 | Eccentric Bushing | | 8 |
| 103 | 174513-902 | Shaft Plate | | 1 |
| 104 | 381393-902 | Bushing | | 10 |
| 105 | 174512-902 | Shaft Plate | | 1 |
| 106 | 174639-000 | Plate | | 2 |
| 107 | 174650-902 | Shaft Plate | | 5 |
| 108 | 174515-902 | Shaft Plate | | 1 |
| 109 | 070070-902 | Toothed Bracket | | 1 |
| 110 | 000104-111 | Cap Screw | M8*1.25P*35 | 2 |
| 111 | 011103-103 | Taper Pin | 5.0*20 | 2 |
| 112 | 000105-102 | Cap Screw | M10*1.5P*25 | 3 |
| 113 | 006001-075 | Flat Washer | 10.3*22*2.0t | 7 |
| 114 | 006001-038 | Flat Washer | 8*16*1.6t | 3 |
| 115 | 000104-106 | Cap Screw | M8*1.25P*20 | 5 |
| 116 | 174656-904 | Scale Seat | | 1 |
| 117 | 174516-902 | Position Bracket | | 1 |
| 118 | 001501-101 | Spring Washer | M8*1.25P*20/8.2*15.4/8.5*19*2t | 4 |
| 119 | 010006-000 | S-Ring | STW-15 | 7 |
| 120 | 320398-000 | Gear | 50T | 1 |
| 121 | 000203-101 | Set Screw | M6*1.0P*6 | 1 |
| 122 | 361301-902 | Worm Gear | | 1 |
| 123 | 011003-114 | Spring Pin | 5*20 | 1 |
| 124 | 012003-001 | Key | 5*5*8 | 2 |
| 125 | 361302-902 | Position Shaft | | 1 |
| 126 | 330067-000 | Bushing | | 3 |
| 127 | 000801-101 | Flat Head Cap Screw | M6*1.0P*10 | 11 |
| 128 | 174518-902 | Plate | | 1 |
| 129 | 006004-070 | Flat Washer | 10*22*0.8t | 1 |
| 130 | 008308-100 | Lock Nut | M10*1.5P(17B*12H) | 1 |
| 131 | 381395-902 | Position Bolt | | 1 |
| 132 | 051407-902 | Bracket | | 1 |

| Key | Part Number | Descriptions | Specifications | QTY |
|-------|-------------|--------------------------------|---------------------------------|-----|
| 133 | 320399-000 | Gear | 30T | 1 |
| 134 | 320397-000 | Gear | 30T | 1 |
| 135 | 000103-103 | Cap Screw | M6*1.0P*12 | 5 |
| 136 | 006001-025 | Flat Washer | 6.4*16*1.0t | 1 |
| 137 | 230114-906 | Handle Chrome | SN 192980 to 192983 | 1 |
| 137 | 230284-000 | Black Folding Handle | SN 192984 and beyond | 1 |
| 138 | 240061-008 | Hand Wheel Chrome | SN 192980 to 192983 | 1 |
| 138 | 240092-008 | Hand Wheel Black | SN 192984 and beyond | 1 |
| 139 | 361304-902 | Handwheel Shaft | SN 192980 to 192983 | 1 |
| 139 | 361395-902 | Handwheel Shaft | SN 192984 and beyond | 1 |
| 140 | 012002-004 | Key | SN 192980 to 192983 | 1 |
| 140 | 012002-006 | Key | SN 192984 and beyond | 1 |
| 141 | 006001-071 | Flat Washer | 10*25*3.0t | 2 |
| 142 | 006703-100 | Wavy Washer | WW-10 | 1 |
| 143 | 174514-902 | Outfeed Table Lock Plate | | 1 |
| 144 | 000105-105 | Cap Screw | M10*1.5P*40 | 4 |
| 145 | 000003-105 | Hex Screw | M8*1.25P*25 | 3 |
| 146 | 008306-100 | Lock Nut | M8*1.25P(13B*9H) | 2 |
| 147 | 174653-902 | Bracket | | 2 |
| 148 | 001502-102 | Spring Washer | M6*1.0P*16/6.5*10.5/6.3*13*1.0t | 4 |
| 149 | 660292-000 | Hydraulic Cylinder | | 2 |
| 150 | 924666-000 | Dust Cover Assembly | | 1 |
| 150.1 | 174654-008 | Dust Cover | | 1 |
| 150.2 | 200106-615 | Sponge | | 1 |
| 151 | 200024-615 | Vibration Absorbing Pad | | 7 |
| 152 | 051430-000 | Base | | 1 |
| 153 | 000003-106 | Hex Screw | M8*1.25P*30 | 1 |
| 154 | 000002-107 | Hex Screw | M6*1.0P*40 | 1 |
| 155 | 008005-100 | Hex Nut | M6*1.0P(10B*5H) | 1 |
| 156 | 174647-000 | Cutterhead Front Cover | | 1 |
| 157 | 000801-104 | Flat Head Cap Screw | M6*1.0P*20 | 2 |
| 158 | 174612-008 | Digital Readout Position Plate | | 1 |
| 159 | 000103-106 | Cap Screw | M6*1.0P*16 | 3 |
| 160 | 000301-204 | Pan Phillips Screw | M3*0.5P*15 | 1 |

| Key | Part Number | Descriptions | Specifications | QTY |
|-----|-------------|--------------------------|------------------------|-----|
| 161 | 006002-139 | Flat Washer | 3*8*1.0t | 2 |
| 162 | 030127-001 | Ball Bearing | 606-ZZ | 1 |
| 163 | 008315-200 | Lock Nut | M3*0.5P(5.5B*4H) | 1 |
| 164 | 360906-902 | Bushing | | 1 |
| 165 | 000002-101 | Hex Screw | M6*1.0P*12 | 1 |
| 166 | 006001-155 | Flat Washer | 6*12*1t | 1 |
| 167 | 174652-000 | Bracket | | 1 |
| 168 | 491128-000 | Sensor | WR5501 | 1 |
| 169 | 174611-008 | Cover | | 1 |
| 170 | 000102-101 | Cap Screw | M5*0.8P*6 | 3 |
| 171 | 021801-000 | Snap Bushing | NB-1722 | 2 |
| 172 | 006001-131 | Flat Washer | 5.3*10*2.0t | 6 |
| 173 | 006001-181 | Flat Washer | 5*16*3.0t | 2 |
| 174 | 950785-000 | Magnetic Strip Assembly | Depth:3/4" | 1 |
| 175 | 002603-702 | Cap Lock Screw | M5*0.8P*16 | 2 |
| 176 | 000805-101 | Flat Head Cap Screw | M4*0.7P*6 | 6 |
| 177 | 574956-000 | Switch Panel | | 1 |
| 178 | 490019-000 | Key Switch | | 1 |
| 179 | 490039-000 | Stop Switch | | 1 |
| 180 | 490040-000 | Start Switch | | 1 |
| 181 | 471037-083 | CSA Cable | SJT18AWG*1C*150mm | 2 |
| 182 | | Battery (local purchase) | AAA | 2 |
| 184 | 006501-100 | Outer Toothed Washer | 4.3*8.5(BW-4) | 1 |
| 185 | 006002-200 | Flat Washer | 4.3*8*0.8t | 1 |
| 186 | 008002-200 | Hex Nut | M4*0.7P(7B*3.2H) | 4 |
| 187 | 491130-000 | Digital Readout | WR5502 (Wixey) | 1 |
| 188 | 174750-000 | Position Bracket | | 1 |
| 189 | 001101-203 | Self-Tapping Screw | M3*1.06P*8 | 2 |
| 190 | 730139-001 | Transmission Cable | Cat 5E* RJ-45-CT-A *2M | 1 |
| 191 | 174770-000 | Switch Box | | 1 |
| 192 | 000302-102 | Pan Phillips Screw | M4*0.7P*8 | 2 |
| 193 | 006001-001 | Flat Washer | 4.3*10*1.0t | 9 |
| 194 | 021103-100 | Zip Tie | ACC-3-B | 1 |
| 195 | 021802-000 | Snap Bushing | NB-2430 | 3 |
| 196 | 924571-000 | Switch Pedestal Assembly | | 1 |
| 197 | 000005-111 | Hex Screw | M12*1.75P*30 | 3 |

| Key | Part Number | Descriptions | Specifications | QTY |
|-------|-------------|----------------------------------|------------------------|-----|
| 198 | 006308-100 | Spring Washer | 12.2*21.6 染 | 3 |
| 199 | 006001-136 | Flat Washer | 12.2*23*2.0t | 3 |
| 200 | 000104-117 | Cap Screw | M8*1.25P*70 | 1 |
| 201 | 006001-054 | Flat Washer | 8.5*20*2.0t | 1 |
| 202 | 381391-308 | Bracket | | 1 |
| 203 | 000403-104 | Pan Phillips Screw | M6*1.0P*20 | 4 |
| 204 | 170479-000 | Rear Access Panel | | 1 |
| 205 | 000101-110 | Cap Screw | M4*0.7*30 | 4 |
| 206 | 000102-102 | Cap Screw | M5*0.8P*8 | 4 |
| 207 | 174651-902 | Bracket | | 2 |
| 208 | 490229-615 | Switch Cover | KSSCB-2 | 2 |
| 209 | 491101-000 | Micro Switch | MJ2-1307 | 2 |
| 210 | 280274-000 | Spring | | 2 |
| 211 | 174642-000 | Belt Guard | | 1 |
| 212 | 001603-102 | Phillip Head Screw w/Flat Washer | M6*1.0P*10/6*13.2*1.0t | 4 |
| 213 | 174641-008 | Dust Port | | 1 |
| 214 | 014343-000 | Poly V-Belt | 490J-9 | 1 |
| 215.1 | 381412-902 | Motor Pulley | | 1 |
| 215.2 | 001903-105 | Set Lock Screw | M8*1.25P*8 | 2 |
| 215.3 | 013003-001 | Key | 1/4"*1/4"*1-1/2" | 1 |
| 215.4 | 008007-100 | Hex Nut | M10*1.5P(17B*8H) | 4 |
| 215.5 | 006001-068 | Flat Washer | 10*20*2.0t | 8 |
| 215.6 | 006307-100 | Spring Washer | 10.2*18.5 | 4 |
| 215.7 | 000105-105 | Cap Screw | M10*1.5P*40 | 4 |
| 215.8 | 021314-000 | Strain Relief | MG25A-18B (w/nut) | 1 |
| 216 | L3606T | Baldor Motor | 3HP 1Ph 230V | 1 |
| | EM3613T | Baldor Motor | 5HP 3Ph 230/460V | 1 |
| 217 | 008009-100 | Hex Nut | M12*1.75P(19B*10H) | 8 |
| 218 | 006001-091 | Flat Washer | 13*28*3.0t | 4 |
| 219 | 380249-901 | Adjusting Shaft Assembly | | 2 |
| 220 | 361303-902 | Supporting Shaft | | 2 |
| 221 | 001902-105 | Set Lock Screw | M6*1.0P*12 | 2 |
| 222 | 190074-901 | Spacer | | 2 |
| 223 | 050321-008 | Motor Mounting Plate | | 1 |
| 224 | 174640-000 | Stand | | 1 |
| 225 | 230403-000 | Foot | | 4 |

| Key | Part Number | Descriptions | Specifications | QTY |
|--|-------------|----------------------------|------------------------|-----|
| 226 | 000103-120 | Cap Screw | M6*1.0P*15 | 2 |
| 227 | 174762-156 | Emergency Stop Foot Switch | | 1 |
| 228 | 280050-000 | Spring | | 2 |
| 229 | 340007-615 | Rubber Packing | | 6 |
| 230 | 000401-104 | Pan Phillips Screw | M4*0.7P*10 | 2 |
| 231 | 170638-156 | Lifting Hook | | 2 |
| 232 | 000303-104 | Pan Phillips Screw | M5*0.8P*12 | 4 |
| 233 | 006502-300 | Outer Toothed Washer | 5.3*10(BW-5) | 2 |
| 234 | 471008-001 | CSA Cable | 10AWG*1C*153mm | 1 |
| 235 | 250573-615 | Bushing | | 4 |
| 236 | 490336-000 | Terminal Socket | HD-30-A3(600V/40A) | 1 |
| 237 | 000303-109 | Pan Phillips Screw | M5*0.8P*35 | 4 |
| 238 | 021314-000 | Strain Relief | MG25A-18B (w/nut) | 1 |
| 239 | 491116-008 | Junction Box Lower Cover | | 1 |
| 240 | 490124-008 | Junction Box Upper Cover | | 1 |
| 241 | 003303-102 | Pan Phillips Screw | 3/16"-24NC*1/4" | 1 |
| 242 | 938013-000 | Switch Assembly | | 1 |
| 242.1 | 170977-901 | Switch Plate | | 1 |
| 242.2 | 823017-042 | Magnetic Switch | | 1 |
| NS | 490270-000 | 220V Magnetic Contactor | MA-18 | 1 |
| NS | 490296-000 | 220V Overload RA-20 | 12 - 18A | 1 |
| 242.3 | 021313-000 | Strain Relief | MG25A-18B (no nut) | 2 |
| 242.4 | 021377-000 | Strain Relief | MG25AS-10B (no nut) | 2 |
| 242.5 | 000303-104 | Pan Phillips Screw | M5*0.8P*12 | 2 |
| 242.6 | 474005-015 | CSA Cable | SJT 10AWG*4C*1000mm | 1 |
| 242.7 | 474005-016 | CSA Cable | SJT 10AWG*4C*760mm | 1 |
| 242.8 | 474001-013 | CSA Cable | SJT 18AWG*4C*1550mm | 1 |
| 242.9 | 472001-050 | CSA Cable | SJT 18AWG*2C*2000mm | 1 |
| <u>Note: 440V 3Phase operation requires special components, contact Oliver Machinery.</u> | | | | |
| NS | 491192-000 | 440V Magnetic Contactor | | 1 |
| NS | 491191-000 | 440V Overload RA-20 | 5.2 - 6.5 - 8A | 1 |
| 243 | 000804-103 | Flat Head Cap Screw | M5*0.8P*10 | 4 |
| 244 | | Label | | |

| Key | Part Number | Descriptions | Specifications | QTY |
|------------|-------------|--------------------|-----------------------|-----|
| 263 | 174618-904 | Fence Cap (Right) | | 1 |
| 264 | 029001-701 | Self-Tapping Screw | M4*1.41*10 | 4 |
| 265 | 174619-904 | Fence Cap (Left) | | 1 |
| 266 | 471037-095 | CSA Cable | SJT 18AWG*1C*900mm | 1 |

Spare Parts

| Part Number | Descriptions | Specifications | QTY |
|-------------------|----------------------------|----------------|-----|
| P-15mm 4S | Insert (Sold in Box Of 10) | | 10 |
| 038201-101 | Torx Screw | #10-32UNF*1/2" | 10 |

Tools for Assembly

| Part Number | Descriptions | Specifications | QTY |
|-------------------|------------------|----------------|-----|
| 250035-629 | Push Blocks | | 2 |
| 040005-000 | Hex Wrench | 5mm | 1 |
| 040006-000 | Hex Wrench | 6mm | 1 |
| 040007-000 | Hex Wrench | 8mm | 1 |
| 040204-000 | Open End Wrench | 12mm/14mm | 1 |
| 040710-000 | Torx Screwdriver | T-25 | 2 |

Warranty and Service

Oliver Machinery makes every effort to assure that its equipment meets the highest possible standards of quality and durability. All products sold by Oliver Machinery are warranted to the original customer to be free from defects for a period of two (2) years on all parts excluding electronics and motors which are warranted for one (1) year from the date of shipment. Oliver Machinery's obligation under this warranty shall be exclusively limited to repairing or replacing products or parts or components, at its sole option, determined by Oliver Machinery to be defective. Oliver Machinery shall not be required to provide other form of indemnity or compensation including but not limited to compensatory damages.

This warranty does not apply to defects due to direct or indirect misuse, abuse, negligence, accidents, unauthorized repairs, alternation outside our facilities, lack of maintenance, acts of nature, or items that would normally be consumed or require replacement due to normal wear and tear.

OTHER TERMS

To obtain and exercise the warranty right, please call 800-559-5065 or fill out warranty request form online at www.olivermachinery.net.

Warranty parts are shipped via Parcel or Ground. Additional charges will occur and charge to customers if express shipping is required.

DISCLAIMER

Under no circumstances shall Oliver Machinery be liable for death, personal or property injury, or damages arising from the use of its products.

Oliver Machinery reserves the right to make changes without prior notice to its products to improve function or performance or design.

FOR MORE INFORMATION

If you need assistance or have questions beyond what is covered in the scope of this warranty information, please call 800-559-5065 or email us at info@olivermachinery.net.

Appendix

US Standard – Metric Conversion Chart

| Fractions | Decimal In. | Millimeters |
|--------------|-------------|-------------|
| 1/64 | .0156 | .396 |
| 1/32 | .0312 | .793 |
| 3/64 | .0469 | 1.190 |
| 1/16 | .0625 | 1.587 |
| 5/64 | .0781 | 1.984 |
| 3/32 | .0937 | 2.381 |
| 7/64 | .1094 | 2.778 |
| 1/8 | .125 | 3.175 |
| 9/64 | .1406 | 3.571 |
| 5/32 | .1562 | 3.968 |
| 11/64 | .1719 | 4.365 |
| 3/16 | .1875 | 4.762 |
| 13/64 | .2031 | 5.159 |
| 7/32 | .2187 | 5.556 |
| 15/64 | .2344 | 5.953 |
| 1/4 | .25 | 6.350 |
| 17/64 | .2656 | 6.746 |
| 9/32 | .2812 | 7.143 |
| 19/64 | .2969 | 7.540 |
| 5/16 | .3125 | 7.937 |
| 21/64 | .3281 | 8.334 |
| 11/32 | .3437 | 8.731 |
| 23/64 | .3594 | 9.128 |
| 3/8 | .375 | 9.525 |
| 25/64 | .3906 | 9.921 |
| 13/32 | .4062 | 10.318 |
| 27/64 | .4219 | 10.715 |
| 7/16 | .4375 | 11.112 |
| 29/64 | .4531 | 11.509 |
| 15/32 | .4687 | 11.906 |
| 31/64 | .4844 | 12.303 |
| 1/2 | .5 | 12.700 |

| Fractions | Decimals In. | Millimeters |
|--------------|--------------|-------------|
| 33/64 | .5156 | 13.096 |
| 17/32 | .5312 | 13.493 |
| 35/64 | .5469 | 13.890 |
| 9/16 | .5625 | 14.287 |
| 37/64 | .5781 | 14.684 |
| 19/32 | .5937 | 15.081 |
| 39/64 | .6094 | 15.478 |
| 5/8 | .625 | 15.875 |
| 41/64 | .6406 | 16.271 |
| 21/32 | .6562 | 16.668 |
| 43/64 | .6719 | 17.065 |
| 11/16 | .6875 | 17.462 |
| 45/64 | .7031 | 17.859 |
| 23/32 | .7187 | 18.256 |
| 47/64 | .7344 | 18.653 |
| 3/4 | .75 | 19.050 |
| 49/64 | .7656 | 19.446 |
| 25/32 | .7812 | 19.843 |
| 51/64 | .7969 | 20.240 |
| 13/16 | .8125 | 20.637 |
| 53/64 | .8281 | 21.034 |
| 27/32 | .8437 | 21.431 |
| 55/64 | .8594 | 21.828 |
| 7/8 | .875 | 22.225 |
| 57/64 | .8906 | 22.621 |
| 29/32 | .9062 | 23.018 |
| 59/64 | .9219 | 23.415 |
| 15/16 | .9375 | 23.812 |
| 61/64 | .9531 | 24.209 |
| 31/32 | .9687 | 24.606 |
| 63/64 | .9844 | 25.003 |
| 1.0 | 1. | 25.400 |



Oliver Machinery is always adding new Industrial Woodworking products to the line.

For complete, up-to-date product information, visit us online at:

WWW.OLIVERMACHINERY.NET

or call toll free 1-800-559-5065

**** SAVE THIS MANUAL FOR FUTURE REFERENCES. ****